

User Manual

## External AUTOMATIC Defibrillator

for public access

4.2

Rev.







# **QUICK USE GUIDE**





©by A.M.I Italia s.r.l.

These instructions for use cannot, without our consent, be completely or partially reproduced, transmitted, stored electronically or translated into another foreign language or computer language. Infractions against this prohibition not only violate our copyright, but also reduce our ability to provide accurate and up-to-date information to the user and the operator of the device.

These instructions for use are subject to changes.

A.M.I Italia S.r.l.

Via Cupa Reginella, 15/A - 80010 Quarto (NA) Italy Tel. +39 081 806 34 75 +39 081 806 05 74 Fax +39 081 876 47 69

E-mail info@amiitalia.com

http://www.amiitalia.com

**Printed in Italy** 



## Summary

1	Introduction		
	1.1	Preface	8
	1.2	Use in accordance with provisions	8
	1.3	Guarantee	8
	1.4	Exclusion of liability	8
	1.5	Indications	8
	1.6	Counter indications	8
	1.7	Version information	9
	1.8	Symbols in the manual	9
	1.9	Manufacturer contacts	9
2	Safe	ty instructions	. 10
	2.1	Indications of DANGER	. 10
	2.2	Indications of CAUTION	. 10
	2.3	Indications of DISPOSAL	. 11
3	Des	cription of the device	. 12
	3.1	Device Information	. 12
	3.2	Service activation procedure	. 14
	3.3	Classifications	. 14
4	Des	cription of device details	. 15
	4.1	General structure of the device	. 15
	4.2	Keys, icons and indicators	. 16
	4.3	Status display	. 16
	4.4	Standard and optional accessories of the device	. 17
5	Part	s and accessories of the Geo Saver	. 19
	5.1	AED Batteries	. 19
	5.1.	1 Non-rechargeable Li-SOCl <sub>2</sub> battery (SAV-C1032)	. 19
	5.1.	2 Rechargeable Li ion battery (SAV-C1033)	. 20
	5.1.	3 Suggestions for a proper maintenance of rechargeable battery SAV-C1033	. 20
	5.1.	4 Inserting and removing the batteries	. 21
	5.1.	5 Recharging station for rechargeable batteries	. 22
	5.1.	6 Battery charger structure	. 22
	5.1.	7 Recharge procedure	. 23
	5.2	Geoloc Batteries	. 24
	5.2.	1 Non-rechargeable Li-SOCl <sub>2</sub> battery (SAV-C1038)	. 24
	5.2.	2 Rechargeable Li ion battery (SAV-C1039)	. 25



	5.2.3	3	Inserting and removing the batteries	26
	5.2.4	4	Recharge procedure	27
	5.3	Defi	brillation PADs	28
	5.3.	1	Defibrillation PADs for Adults SAV-C0846	28
	5.3.2	2	PADs for Children SAV-C0016	28
	5.3.	3	Positioning of defibrillation PADs	29
	5.4	Men	nory Card and USB	30
6	Auto	o test		31
	6.1	Disp	lay and control LED	31
	6.2	ACT	IVATION Test	32
	6.3	AUT	OMATIC Test	32
	6.4	POV	VER ON Test	33
7	Info	rmati	on button	34
8	Defi	brilla	tion	35
	8.1	Swit	ching on the <i>Geo Saver</i>	35
	8.2	Prep	paration of the patient	36
	8.3	Posi	tioning the PADs	36
	8.4	Carc	liac rhythm analysis	37
	8.5	Shoo	ckable rhythm	38
	8.6	Chai	nge of rhythm	39
	8.7	Non	-shockable rhythm	39
	8.8	CPR		39
9	Reco	ordin	g, viewing and archiving the data	41
	9.1	Data	a recording	41
	9.2	Arch	iiving data on PC	41
1(	) v	/eb N	1anagement	42
	10.1	Maii	n features	43
	10.1	1	Changing the language	43
	10.1	2	User profile and password	43
	10.1	3	Device management	44
	10.1	4	ECG Streaming	45
	10.1	5	Auto tracking	46
	10.1	6	Battery replacement	46
	10.1	7	Firmware update	47
	10.2	Dasł	nboard	48



10.3	Devices	49
10.4	Geo Saver	50
10.5	Saver Log	51
10.6	Geoloc Log	52
10.7	Streaming	53
10.8	List of saved ECG Streaming	54
10.9	Tracks	55
11 N	Aaintenance	56
11.1	After each use	56
11.2	Ordinary maintenance	56
11.3	Cleaning	57
11.4	Preservation	57
11.5	Troubleshooting Guide	58
12 T	echnical specifications	59
12.1	Physical characteristics	59
12.2	Environmental requirements	59
12.3	Reference regulations	59
12.4	Alarms table	60
12.5	Controls and indicators	60
12.6	Data memory	60
12.7	Defibrillator	61
12.8	Efficiency of delivered energy	62
12.9	Patient analysis system	64
12.10	ECG Analysis Function	64
12.11	Non rechargeable battery	64
12.12	Rechargeable battery	65
12.13	Internal back-up battery	65
12.14	Rechargeable battery charger	65
12.15	Defibrillation PADs	65
12.16	Timing of Shock cycles	66
12.17	Geoloc Module	66
12.18	Geoloc Module Battery Type	66
13 C	Compliance with electromagnetic emission standards	67
13.1	Guidelines and manufacturer's declaration - Electromagnetic emissions	67
13.2	Guidelines and manufacturer's declaration - Electromagnetic immunity	67



	Recommended separation distance between portable and mobile RF communication equipmen Geo Saver device	
14	Simbology	70
15	Certifications	71
15.1	EC Certificate	71
15.2	IMQ Brand	73
16	Geo Saver Series Defibrillator Warranty	74
17	Product registration	75



## 1 Introduction

## 1.1 Preface

Thank you for having chosen the defibrillator of A.M.I Italia S.r.l. model Geo Saver.

So that you can correctly use the device it is necessary, before usage, to carefully read this user manual. The User Manual of *Geo Saver* contains the instructions for its use in compliance with its function and purpose. For a function free of error and to achieve the right benefits, it is fundamental to respect the prescriptions indicated in this user manual, to guarantee the safety of the patient, of the rescuer and of any third parties. This manual is an integral part of the defibrillator and must always be kept together with the device, so that it can be easily accessible if necessary.

## 1.2 Use in accordance with provisions

The device *Geo Saver* can be used exclusively if the conditions indicated in the user manual are respected. Any use not as prescribed meaning not in accordance with the provisions can cause damage to people or objects. In such cases A.M.I. Italia S.r.I declines all responsibility.

## 1.3 Guarantee

The device *Geo Saver* has a guarantee of 6 (six)\*years.

The non-rechargeable battery Li-SOCl<sub>2</sub> (SAV-C1032) has a guarantee of 4 (four)\* years in Stand-by mode (assuming a battery activation test, daily self-tests without turning on the AED). This information refers to new batteries, fully charged at a temperature of  $20^{\circ}$ C and humidity of 45%.

\* For more information consult Chapter 16 "Guarantee contract for defibrillators Geo Saver Series"

## 1.4 Exclusion of liability

The rights of liability are excluded in cases of damage to people or objects, if attributable to one of the indicated causes:

- Use of the appliance not in compliance with the provisions.
- Improper use and maintenance of the appliance.
- Use of the device and / or its accessories which show obvious or partial damage.
- Failure to comply with the instructions in the user manual concerning precautions, operation, maintenance and repair of the appliance.
- Use of non-original accessories and/or parts not approved by the manufacturer.
- Arbitrary interventions, repairs or modifications of the device.
- Arbitrary overcoming of performance limits.
- Lack of surveillance of parts subject to wear.

## 1.5 Indications

Geo Saver can only be used if the patient:

- is unconscious and...
- does not breathe and...
- shows no signs of blood circulation

## 1.6 Counter indications

Geo Saver cannot be used if the patient:

- is in a conscious state or...
- shows normal respiration or...
- shows signs of blood circulation



### **1.7 Version information**

This user manual has a version number. The version number changes every time the manual is updated for changes made to the function of the device or to the device itself. The contents of this user manual are subject to change without notice. The information on the version of this manual is as follows.

Version number:	4.2
Issuing date:	01/09/2020

## 1.8 Symbols in the manual

In this user manual there are several symbols that indicate the various precautions for use:

SYMBOL	INDICATION	DESCRIPTION
$\mathbf{\mathbf{N}}$	DANGER	Indicates an immediate risk to the safety of people, which also <b>involves death</b> and damage to the device or parts thereof
ľ	CAUTION	Indicates an unsafe situation or practice <b>involving</b> <b>serious personal injury</b> and damage to the device or parts thereof

#### **1.9 Manufacturer contacts**

You can contact our company at the following addresses:

#### A.M.I. Italia S.r.l.

#### **REGISTERED OFFICE**

Via G. Porzio Centro Direzionale Isola G/2 80143 Napoli (NA) Italy

#### PRODUCTION SITE ITALY

 PRODUCTION, LABORATORIES, OFFICES

 Via Cupa Reginella, 15/A

 80010 Quarto (NA) Italy

 Phone:
 +39 081 806 34 75

 Fax:
 +39 081 876 47 69

#### PRODUCTION SITE HUNGARY PRODUCTION, LABORATORIES, OFFICES A.M.I. International KFT

Kőzúzó u. 5/A 2000 Szentendre (Hungary) Phone: +36 26 302.210

Assistance request

email: Phone: Website <u>info@amiitalia.com</u> +39 081 806 05 74 www.amiitalia.com



## 2 Safety instructions

For a correct use of the *Geo Saver* defibrillator, users must be aware of the safety factors listed below.

#### Please read them carefully.

The *Geo Saver* defibrillator, individually and in connection with its standard and optional (original) accessories, complies with the safety regulations currently in force and is in compliance with the provisions of the directives on medical products.

The appliance and its accessories are to be considered safe in the case of application according to the provisions and if the descriptions and indications listed in this user manual are respected.

The following are the main precautions to be taken for the correct and safe use of the defibrillator, divided for easy consultation between hazard indications, warning indications and disposal instructions.

## 2.1 Indications of DANGER

- Use the Geo Saver in accordance with the prescriptions in this user manual. Carefully read these instructions for use and in particular the safety instructions indicated in them.
- In accordance with IEC standards (section 2.4), the use of the Geo Saver device or its accessories in the presence of flammable substances (petrol or similar) or in an atmosphere enriched with oxygen or flammable gases / vapors is not allowed.
- Do not recharge the Li-SOCl2 battery (SAV-C1032). Explosion risk!
- > Do not allow the batteries to come into contact with an open flame. Do not expose to fire.
- Do not short circuit the battery terminals.
- > In case of leakage of liquids or strange smells from the batteries, keep them away from fire to prevent any leaked electrolytes from catching fire.
- Danger of electric shock. The device generates high voltages and dangerous levels of current.
- Do not open the Geo Saver, do not remove the panels and do not attempt to repair it. The Geo Saver contains no components that users can repair. For repair purposes, the Geo Saver P must be sent to an authorized technical service center.
- Do not apply the electrodes to the patient's chest if nitroglycerin patches are present. Remove the patches and only then position the electrodes. Otherwise there is a risk of causing an explosion.
- > Do not touch the patient and prevent third parties from coming into contact with the patient during the defibrillation shock phase. Avoid any contact between:
  - parts of the patient's body
  - conductive liquids (such as gel, blood or solution of table salt)
  - metal objects in the surroundings of the patient (such as bed frame or stretching device) that represent indirect ways for the defibrillation current
- Before using the device ensure the patient's safety, if necessary move them carefully and position them in a safe place as per the
- AHA / ERC 2017 guidelines
- > Do not immerse any part of the *Geo Saver*, its parts or accessories in water or other liquids.
- Do not allow liquids to enter the Geo Saver its parts or accessories. Avoid spilling liquid on the device and its accessories. Failure to do so may cause damage or cause a risk of fire or electric shock. Do not sterilize the Geo Saver or its accessories.





- Avoid the formation of air bubbles between the skin and defibrillation PADs. The formation of air bubbles during defibrillation can cause severe burns to the patient's epidermis. To avoid the formation of air bubbles, make sure that the electrodes fully adhere to the skin. Do not use electrodes whose gel has dried, check the expiration date before use.
- Do not delay treatment in patients with an implanted pacemaker and perform a defibrillation attempt if the patient has lost consciousness and is not breathing or breathing normally. The *Geo Saver* is equipped with a pacemaker detection system that allows ignoring the signal emitted by the latter; however, with some types of pacemakers, *Geo Saver* may discourage a defibrillation shock.

During the application of the electrodes:

• Do not apply the electrodes directly to an implanted device.

- Apply the electrodes at least 2.54 cm (1 inch) from any implanted device
- RF (radio frequency) interference, caused by devices such as cellular phones and two-way radios, can cause the *Geo Saver* to malfunction. The *Geo Saver* must be kept at least 2 meters away from these RF devices, as indicated in the standards of EN 61000- 4-3. Keep away from other therapeutic and diagnostic energy sources (eg diathermy, high-frequency surgery, magnetic tomography).
- Use the *Geo Saver* only if you have achieved a BLS-D or ALS-D training course.
- Before using the device, make sure that there is no obvious damage.
- > The infrared interface emits optically invisible radiation. The emission diode complies with IEC/EN 60825-1 Class 1 "Eye Save"
- Do not use pediatric defibrillation PADS (SAV-C0016) on adult patients (older than 8 years and weighing more than 25Kg). Using pediatric defibrillation PADS the *Geo Saver* automatically switches to pediatric mode, reducing the maximum energy available to 50J.
- Arrange the patient cables so as to reduce the possibility of wrapping or strangling the patient.



- > In a domestic environment, keep the defibrillator out of the reach of children and pets.
- Do not apply the defibrillation electrodes directly on an implanted pacemaker to avoid any errors in the interpretation of the device and to avoid damage to the pacemaker through the defibrillation impulse.
- Disconnect high-voltage pulse-sensitive equipment from the patient ie that is not defibrillator-proof, before delivering the shock.





- Do not allow defibrillation electrodes to touch or come into contact with ECG electrodes, swabs, transdermal patches, etc. Failure to do so may result in creation of electric arcs and burns to the patient during defibrillation, and even current leakage.
- Position the defibrillation PADS as indicated in this user manual and indicated on the package.
- > Do not use defibrillation PADs if the gel has been detached from the support or is torn, split or dry.
- > If damage has been detected, do not operate the *Geo Saver* under any circumstances.
- Before using the device, remove metal objects from the patient's body (including necklaces or bracelets, etc.)
- > Do not use defibrillation PADs other than those supplied by the manufacturer. Otherwise, the defibrillator may make false interpretations.
- > Do not use defibrillation PADs if they are damaged, even partially.
- > Do not touch the patient or PADs during heart rhythm analysis.
- Moving or transporting the patient during the cardiac rhythm analysis performed by the device can lead to an incorrect or not timely diagnosis. During the heart rhythm analysis phase, minimize the movements. If the device is used in an ambulance in motion, stop the vehicle and start again only after having delivered the shock.
- In order to use the Geo Saver, you must have completed a training course for basic or advanced cardio-pulmonary resuscitation with the use of a defibrillator (BLS-D or ALS-D course)
- Avoid the use of adult defibrillation PADs (SAV-C0846) on children (ages 1-8 years or 8-25kg).
- > Before applying the defibrillation PADS, if necessary, dry the patient's chest and remove unwanted hair.
- > Do not subject Geo Saver, its accessories, its parts to falls and / or strong impacts
- > Do not use damaged accessories and / or parts, otherwise the device may malfunction.
- Use only original accessories and / or spare parts.
- Avoid excessively aggressive handling of the device of its accessories or parts in order to avoid possible damage. Inspect the entire system periodically.
- Carry out the sanitation operations of the device in compliance with the standards indicated in paragraph 10.3 and always make sure that the device is switched off with the battery removed and PADs disconnected.
- Defibrillation PADs are disposable, to be used only on one patient. Do not reuse defibrillation pads; discard after use and replace with a new pair.
- Defibrillation PADs are not sterile or sterilizable.
- Intense or prolonged administration of cardiopulmonary resuscitation with defibrillation electrodes applied to the patient can damage the electrodes. Replace them if they are damaged due to use or handling.
- > Improper maintenance can damage the Geo Saver or cause it to malfunction. Follow the instructions in this user manual.
- Use original non-rechargeable Li-SOCl2 (SAV-C1032) batteries from A.M.I. Italia S.r.I. before the indicated expiration date.
- Recharge the rechargeable Li-ion battery (SAV-C1033) at least once every 4 months ensure its perfect function and extend its life.
- The Li-ion rechargeable batteries ACC model (SAV-C1033) must be charged using only the SAV-C1035 battery charger from A.M.I. Italia S.r.l. otherwise the batteries could be damaged
- Remove the batteries from the device only if it has been turned off for at least 5 seconds. Otherwise the device and the battery can be seriously damaged.
- > The *Geo Saver*, its parts and accessories are not sterile or sterilizable
- > Do not expose the *Geo Saver*, its parts or accessories to direct light or high temperatures
- The Battery Charger (SAV-C1035) must only be used with the Meanwell power supply model GS40A15-PIJ (SAV-C1037) supplied by A.M.I. Italia S.r.I. The use of different power supplies could compromise the correct functioning of the battery charger and damage the ACC rechargeable batteries (SAV-C1033)
- In order to safeguard the battery life (SAV-C1032) and guarantee automatic daily tests, after installing it, it is advisable to not remove the battery (SAV-C1032) unless it is to be replaced. The removal of the battery and the subsequent insertion involves a complete test of the AED which considerably consumes its capacity. Furthermore, if the battery is not properly attached it could be damaged.

### 2.3 Indications of DISPOSAL



The Geo Saver, its parts and accessories must not be disposed of with other household waste within the European community. To prevent possible damage to the environment or human health caused by incorrect waste disposal, recycle this product responsibly also to promote sustainable use of resources. To dispose of the used product, use the appropriate waste collection services or return it to the local distributor. In this way it will be possible to recycle safely for the environment



## 3 Description of the device

## **3.1 Device Information**

Geo Saver Automatic is called PAD or Public Access Defibrillator.

*Geo Saver Automatic* is a FULLY AUTOMATIC external defibrillator meaning that if an arrhythmia that requires a shock is detected the device will automatically deliver the defibrillation shock. Designed to automatically detect and analyze the victim's heart rhythm, it is capable of delivering one or more defibrillation shocks if ventricular fibrillation or ventricular tachycardia (monomorphic or polymorphic with beat> 180) is detected. The energy is supplied by an exponential truncated biphasic electrical shock (B.T.E.) able to adapt to the patient's thoracic impedance. The *Geo Saver Automatic* is available in two versions:

**Geo Saver 200J** (SGA-B0990) – Maximum deliverable energy 200J **Geo Saver 360J** (SGA-B0991) – Maximum deliverable energy 360J

The Geo Saver is an extremely compact and lightweight portable device; it can be used with two types of battery:

- Non-rechargeable battery Li-SOCl<sub>2</sub> (SAV-C1032), which requires no maintenance, is guaranteed to operate in standby mode for 4 years or carry out a high number of shocks
- Rechargeable battery Li-Ion (SAV-C1033), recommended for those who use the defibrillator intensively

*Geo Saver Automatic* has been designed to be used not only by medical personnel but also by lay personnel who have duly completed a training course on cardio-pulmonary resuscitation with the use of the defibrillator (BLS-D). The *Geo Saver Automatic* is equipped with voice commands that instruct the rescuer in every phase of resuscitation. The device has been designed for rapid use to facilitate use by the user.

The device is built in accordance with directive 2007/47 / EC and complies with IEC/EN 60601-2-4.

The device allows the data to be recorded on an SD Memory Card so that they can be re-displayed on a PC. During the non-use phase, if battery is installed, the device carries out daily self-tests to verify its functional condition, in order to guarantee its prompt use in the moment of need. On the keyboard of the device there is a mini LCD display and a two-color LED (red / green) through which it is possible to see the outcome of the functional tests and to know the functional status of the device even if switched off (stand-by mode).

Geo Saver is a defibrillator equipped with a SIM card, GPS and a battery power system. These characteristics make it an extremely versatile device suitable for installation both in public practices and in constantly moving vehicles such as trains or buses.

The presence of a SIM card allows the Geo Saver to transmit and receive data through the mobile telephone network. The GPS makes it possible to track the movements.

The battery power supply of the system dedicated to Geolocation and communication via mobile phone network is autonomous and additional to that of the components dedicated to the basic functionality (defibrillator).

The information that the Geo Saver sends remotely are consultable through the web platform

<u>http://www. AMISAVERCLOUD.com</u> which is accessible from any device with a browser (PC, tablet or smartphone); no dedicated equipment or software is required.

Each user will be able to access the AMIAMISAVERCLOUD platform in a safe way through the use of personalized credentials; then he will be able to quickly visualize the location and status of their Geo Savers.



Compared to a classic defibrillator, the main differences are:

- Remote control
- Telemetry
- Geo-location
- Teleservice
- Management of AEDs and AEDs' users
- Updates through remote connection

#### **Remote control**

Thanks to the AMISAVERCLOUD it is possible to control the device quickly and easily.

By accessing the section dedicated to each Geo Saver it is possible to configure each aspect by sending simple commands and knowing the last ones sent.

#### Telemetry

The Geo Saver connects with the portal at least once a day and sends an AED log containing its parameters and status information, which are consultable through the access to the AMISAVERCLOUD:

- Each Geo Saver is represented by a coloured icon which will allow the immediate recognition of its status :
  - Green: ready to use device;
  - Yellow: Warning of an anomaly that does not affect the defibrillator functionality;
  - Red: device failed, service required;
- The consultation of logs allows the user to carry out the check of the device and its accessories.

In case of connection failure (due to lack of network coverage or malfunctions), AMISAVERCLOUD will notify the disservice to the owner via SMS or email.

#### **Geo-location and Anti-theft**

For any Geo Saver is possible to:

- locate the last position on a map;
- tracking the movements (auto tracking) and visualize the path on the map through the web portal;
- notify the owner whenever it is moved, by configuring on the AMISAVERCLOUD the "antitheft" functionality. In this case, the web portal will send a message (via SMS or email) as soon as the device detects a movement.

#### Teleservice

#### Streaming ECG

The Geo Saver system allows the ECG to be transmitted in real time to AMISAVERCLOUD and, through the web portal, it is possible to monitor the signal.

All the recorded ECGs are saved in the portal and made available for future consultations.

#### LIVE call

During a rescue it is possible to make a voice call directly from the Geo Saver to the local EMS using a dedicated button.

Through the portal, it is possible to assign up to three telephone numbers to which the call is addressed. The telephone numbers must be set according to the regulations in place in the individual countries where the Geo Saver is installed.



### 3.2 Service activation procedure

In order for the Geo Saver series defibrillators to fully provide the features for which they were designed, it is necessary to follow the service activation procedure.

- 1. Check that the SIM card (\*) supplied is correctly inserted;
- 2. Make sure you are in an area covered by a GSM / GPRS signal;
- 3. Insert the battery for the Geoloc module into the battery compartment;
- 4. Insert the Geo Saver battery into the battery compartment;
- 5. Check that the Geo Saver performs the test designed for battery insertion;
- 6. Turn off the Geo Saver;
- 7. Wait a minute and check on the AMISAVERCLOUD the arrival of the session log on the page related to the device being activated.

(\*)

- The SIM cards supplied by the manufacturer only work if inserted in Geo Saver type equipment;
- Each SIM card supplied by the manufacturer only works if inserted in the Geo Saver to which it is paired;
- A SIM card associated with a Geo Saver does not work if inserted in another Geo Saver series device;

## 3.3 Classifications

The Automatic Geo Saver defibrillator is classified as follows:

Code UMDNS	11132
Code GMDN	47910
Code CND	Z12030503
Directory number <b>RDM</b>	1793149 / 1793155
Code CIVAB	DEF03
Class of belonging according to directive 2007/47/CE	IIb
Type of protection against electric shock	Internally powered
Type of patient isolation	BF
Degree of protection against penetration of liquids	IPx6
Degree of protection against dust penetration	IP5x
Degree of safety in the presence of a flammable anesthetic mixture with air, oxygen or nitrous oxide	Not protected
Sterilization or disinfection method suggested by the supplier	See Paragraph 11
Mode of operation	Continuous operation



## 4 Description of device details

## 4.1 General structure of the device



Nr.	Description
1	Compartment for PADS connector or ECG
	cable
2	Live call button
3	Microphone for environmental recordings
4	Status mini display
5	Carrying handle
6	Keyboard with buttons and light icons
7	IrDA port (service only, present only in the
	models with TFT display)
8	Loudspeaker
9	Live call microphone



Nr.	Description	
10	USB port	
11	Compartment for SD Memory Card	
12	Compartment for SIM card	
13	Geo Saver battery compartment	
14	Geoloc battery compartment	
15	Live call speaker	





## 4.2 Keys, icons and indicators




Image 3

Nr.	Function	Nr.	Function
1	<b>"Patient Type" Indicator</b> Indicates the type of mode in use: <b>Adult</b> if you insert Adult PADs <b>Child</b> if you insert pediatric PADs	6	<b>Product logo</b> Indicates the model of the device
2	"Place PADs" Indicator Icon equipped with LEDs indicating to position the defibrillation PADs.	7	"CPR" Indicator Indicates to start CPR
3	<b>Control LEDs</b> Luminous LED (red / green) allows you to check the functional status of the AED.	8	"Do Not Touch" Indicator Icon equipped with LEDs indicating not to touch the patient during certain operations
4	<b>ON / OFF button</b> Allows you to switch the device on or off.	9	"Automatic Shock" indicator Icon equipped with LEDs indicating that the defibrillation shock is about to be delivered automatically
5	Status mini display It allows you to check the functional status of the device	10	<b>''I'' button</b> Allows in operating mode to show useful information on the device

## 4.3 Status display



Nr.	Description	
1	Device status icon	
2	Remaining battery level	
3	Text commands	



## 4.4 Standard and optional accessories of the device

The Geo Saver defibrillator comes with the following standard accessories:

Code	Image	Quantity	Description
SGA-B0990		1 Unit	Geo Saver 200J
SGA-B0991		(Version 200J or 360J)	Geo Saver 360J
SAV-C0846	Ø 🗋	1 Unit	Adult Pads
SAV-C1032		1 Unit	Li-SOCl <sub>2</sub> AED Disposable battery
SAV-C1073		1 Unit	User guide
SAV-C1038		1 Unit	Li-SOCl <sub>2</sub> Geoloc disposable battery
SAV-C1071		1 Unit	SIM card



The following are the optional *Geo Saver* accessories that can be purchased separately:

Code	Image	Quantity	Description	
SAV-C1033		1 Unit	ACC Rechargeable Li-Ion battery	
SAV-C1035	<u>(</u>	1 Unit	Charger	
SAV-C1037		1 Unit GS40A15-P1J Power supply		
			N.01 Charger	
SAV-C1034		1Unit	N.01 GS40A15-P1J Power supply	
		(Contains 3 units)	N.01 Power supply cable	
SAV-C0016	SA I	1 Unit	Children Pads	
SAV-C0019		1 Unit	CD-ROM Saver View Express	
SAV-C0906	20- **	1 Unit	SD Card	
SAV-C0027		1 Unit	Memory Card reader for PC	
SAV-C1072		1 Unit	Carry bag	
SAV-C1039	-	1 Unit	Li-Ion Geoloc rechargeable battery	
SAV-C1040		1 Unit	Geoloc battery charger	



## 5 Parts and accessories of the *Geo Saver*

### 5.1 AED Batteries

The Geo Saver defibrillator can work with two different types of batteries:

- (SAV-C1032) Non-rechargeable Li-SOCl<sub>2</sub> battery
- (SAV-C1033) Rechargeable Li-Ion battery

#### 5.1.1 Non-rechargeable Li-SOCl<sub>2</sub> battery (SAV-C1032)

The non-rechargeable battery with Li-SOCl<sub>2</sub> technology (SAV-C1032) is supplied fully charged and ready for use. The Li-SOCl<sub>2</sub> non-rechargeable battery has been designed to have a long battery life and no maintenance whatsoever.



The non-rechargeable battery of the *Geo Saver* in Standby mode is guaranteed for 4 (four) years<sup>\*1</sup> assuming a battery activation test, daily self-tests without turning on the AED. The Li-SOCl<sub>2</sub> non-rechargeable battery (SAV-C1032) is able to carry out a large number of shocks which vary according to the version:

Geo Saver Standard 200J300 complete rescue cycles (shocks at 200J. and CPR)\*1Geo Saver Power 360J200 complete rescue cycles (shocks at 360J. and CPR)\*1\*1New and fully charged battery, constant temperature at 20°C and relative humidity without condensation 45%

In this condition the use of the device is not recommended.

If the remaining battery level is low, the *Geo Saver* informs the user via audio and visual messages. The *Geo Saver* will give a low battery warning when the level is  $\leq 5\%$  (WARNING) and a very low battery warning when the level is  $\leq 1\%$  (ALARM)

WARNING:	Remaining capacity level of Battery equal or less than 5%.
	This notice will only be provided in Operating mode as indicated in paragraph 6.1.
	With a 5% battery the Geo Saver allows to shock about 14 shocks or 40 days of stand-by* <sup>2</sup>
ALARM:	Remaining capacity level of Battery at $\leq 1\%$
	This warning will be provided both in Stand-by and in operating mode, as indicated in paragraph 6.1
	With a battery at $\leq 1\%$ the <i>Geo Saver</i> carries out about 7 shocks or 20 days of stand-by* <sup>2</sup>

 $*^2$ , Constant temperature at 20°C and relative humidity without condensation 45%

#### **!!ATTENTION!!**

In order to protect the battery life (*SAV-C1032*) and guarantee automatic daily tests, after installing it, it is advisable not to remove the battery (*SAV-C1032*) unless it is replaced. The removal of the battery and the subsequent insertion involves a complete test of the AED which considerably consumes its capacity. Furthermore, if the battery is not properly attached it could be damaged.



#### 5.1.2 Rechargeable Li ion battery (SAV-C1033)

The rechargeable battery with Li-ion technology (SAV-C1033) of the *Geo Saver* is suitable for those who use the defibrillator intensively. Being rechargeable, it allows operators to reduce management costs and guarantee a greater number of interventions.



The ACC rechargeable battery of the *Geo Saver* can be recharged using only the dedicated charger (SAV-C1035) with relative accessories supplied by A.M.I. Italia S.r.l. The battery allows you to carry out a high number of shocks which varies according to the version of the *Geo Saver* in your possession:

Geo Saver Standard 200J	typically 250 continuous shocks *1
Geo Saver Power 360J	typically 160 continuous shocks *1

\*1 New and fully charged battery, constant temperature at 20°C and relative humidity without condensation 45%

If the remaining battery level is low, the *Geo Saver* informs the user via audio and visual messages. The *Geo Saver* will give a low battery warning when the level is  $\leq 5\%$  (WARNING) and a very low battery warning when the level is  $\leq 1\%$  (ALARM)

WARNING:	Remaining capacity level of Battery equal or less than 5%.		
	This notice will only be provided in Operating mode as indicated in paragraph 6.1.		
	With a 5% battery the Geo Saver P allows to shock about 14 shocks or 40 days of stand-by* <sup>2</sup>		
ALARM:	Remaining capacity level of Battery at $\leq 1\%$		
	This warning will be provided both in Stand-by and in operating mode, as indicated in paragraph 6.1		
	With a battery at $\leq 1\%$ the <i>Geo Saver</i> carries out about 7 shocks/20 days of stand-by* <sup>2</sup>		
	In this condition the use of the device is not recommended.		

\*<sup>2</sup>, Constant temperature at 20°C and relative humidity without condensation 45%

It is advisable to replace these batteries every 2 years or after having made a number of recharges greater than **300** (the event that occurs first).

#### 5.1.3 Suggestions for a proper maintenance of rechargeable battery SAV-C1033

A.M.I Italia recommend that batteries SAV-C1033 left in a "storage stage" to be fully recharged at least every 4 months from the receipt of the goods and to be recharged regularly every 4 months when attached to the device "ready to use", to avoid completely discharging it and to maintain maximum life expectancy of the battery. The battery pack technology and the modules offered are to ensure a long lasting duration but they require a correct maintenance; failure to follow these requirements will result in an early deterioration of the battery, which will not be covered by warranty.

For warranty replacement consideration, batteries are to be returned to the original supplying distributors/dealer.



#### 5.1.4 Inserting and removing the batteries

To be able to operate the *Geo Saver* the insertion of a battery is required. Below are detailed instructions for correctly installing the batteries (rechargeable or non-rechargeable) in the *Geo Saver*.



- Position the appliance on its side as shown in image (6)
- Remove the cover of the battery compartment as shown in image (6)
- Insert the battery as shown in image (7)
- Push the battery as shown in image (7) positioning it at the bottom of the special compartment
- Close the battery compartment cover as shown in image (8)

Follow the instructions below to **remove** the battery in the device:



- Position the device as shown in image (9)
- Hold the device firmly with your left hand as shown in image (10)




#### 5.1.5 Recharging station for rechargeable batteries

The charging station (SAV-C1034) allows you to recharge rechargeable batteries with Li-Ion technology ACC model (SAV-C1033) of the *Geo Saver*. The charging station consists of the following parts:

- Charger (SAV-C1035) image (11)
- AC/DC power supply/adapter model GS40A15-P1J (SAV-C1037) image (12)
- Power cable with three-pole Italian plug (SAV-C0366) image (13)



#### 5.1.6 Battery charger structure



The Battery Charger (SAV-C1035) must only be used with the AC/DC power supply/adapter supplied by A.M.I. Italia S.r.l. model GS40A15-P1J of Meanwell (SAV-C1037).

The battery charger (SAV-C1035) and the relative power supply unit (SAV-C1037) are not certified under the supervision of the IMQ notified body, therefore they do not fall into the EC certificate no.1104 / MDD. Furthermore, these devices do not have the IMQ mark, therefore they are not indicated in the IMQ certificate no. CA10.00185.



#### 5.1.7 Recharge procedure

- A Place the charger on a perfectly horizontal shelf and firmly attached to the floor
- **B** Connect the power supply (SAV-C1037) to the charger and then to the power outlet
- C The LED on the charger will flash green, indicating that it is ready to charge
- **D** Insert the battery to be charged into the battery charger as shown in image (15)



The recharging station allows you to recharge exclusively original ACC rechargeable Li ion batteries (SAV-C1033) of A.M.I. Italia S.r.I. The charging time of around 2.5 hours may increase in the case of batteries that have undergone recharging cycles higher than the one indicated. The battery charger is equipped with a control LED that indicates both its functional status and the battery charge level, if inserted. The following is a table that allows identification of the control LED coding:

INDICATOR	]	RED	GREEN			
FIXED	Battery	not working	Battery	Battery charge completed		
	Battery inserted	Faulty battery charger	Battery inserted Battery charging			
FLASHING	Battery not inserted		Battery not inserted	Battery charger waiting for battery insertion		

When recharging, the battery charger control LED will flash green with a different frequency depending on the level of recharge, until the charge is fully indicated by the control LED with FIXED green light.

es.

		ं	o o	O O O	Č	•
	Charge level	0%	25%	50%	75%	100%
Γ	Number of consecutive flashes	1	2	3	4	Fixed



### 5.2 Geoloc Batteries

The Geoloc Geo Locator can work with two different types of batteries:

- (SAV-C1038) Non-rechargeable Li-SOCl<sub>2</sub> battery
- (SAV-C1039) ACC Rechargeable Li-ion battery

#### 5.2.1 Non-rechargeable Li-SOCl<sub>2</sub> battery (SAV-C1038)

The non-rechargeable battery with Li-SOCl<sub>2</sub> technology (SAV-C1038) is supplied fully charged and ready for use. The Li-SOCl<sub>2</sub> non-rechargeable battery has been designed to have a long battery life and no maintenance whatsoever.



Image 16

The *Geoloc* non-rechargeable battery in Standby mode is guaranteed for 4 (four) years<sup>\*1</sup>assuming a machine activation test, daily self-test without any connection to the AMISAVERCLOUD for transfers other than the session log and a good coverage for GPS and GPRS signal.

If the remaining battery level is low, *AMISAVERCLOUD* highlights the status by coloring yellow or red the graphic representation (pie chart) of the remaining capacity and eventually informs the user by sending e-mail or sms if sending was enabled from the specific configuration panel (par. 10.4)

#### **!!ATTENTION!!**

The rechargeable batteries require maintenance which consists of a complete recharge every 4 months



#### 5.2.2 Rechargeable Li ion battery (SAV-C1039)

The rechargeable battery with Li-ion technology (SAV-C1039) of the *Geoloc* is recommended for those who intensively use the unique features of the Geo Saver- Geoloc -AMISAVERCLOUD system (Streaming, Speakerphone calls, tracking). Being rechargeable, it allows operators to reduce management costs and guarantees a greater number of connections.



Image 17

The ACC rechargeable battery of the *Geo Saver* can be recharged using only the dedicated charger (SAV-C1040) with relative accessories supplied by A.M.I. Italia S.r.l.

If the remaining battery level is low, the *AMISAVERCLOUD* highlights the status by coloring yellow or red the graphic representation (pie chart) of the remaining capacity and eventually informs the user by sending e-mail or sms if sending was enabled from the specific configuration panel (par. 10.4).


#### **!!ATTENTION!!**

The rechargeable batteries require maintenance which consists of a complete recharge every 4 months



#### 5.2.3 Inserting and removing the batteries

In order to function, the *Geoloc* module requires the insertion of a battery. Below are the detailed instructions for correctly installing the batteries (rechargeable or non-rechargeable) for the *Geoloc* module inside the *Geo Saver*.



- Remove the cover from the battery compartment as shown in image (18)
- Hook the Battery connector to the Geoloc as shown in image (19)
- Insert the battery
- Close the battery compartment cover as shown in image (20)

Follow the instructions below to remove the battery from the device:



- Open the cover of the Geoloc battery compartment as shown in image(21)
- Remove the battery
- Disconnect the battery connector as shown in image (22)



#### 5.2.4 Recharge procedure

- A Remove the rechargeable battery (SAV-C1039) from the Geo Saver
- **B** Connect the battery charger (SAV-C1040) to the power outlet
- C Hook the connector of the battery charger / power supply into the battery as shown in image (23)



The recharging station allows recharging exclusively original ACC rechargeable Li ion batteries (SAV-C1039) of A.M.I. Italia S.r.1 .The charging time of around 2.5 hours may increase in the case of batteries that have undergone recharging cycles higher than the one indicated. The battery charger is equipped with a control LED that indicates both its functional status and the battery charge level, if inserted. The following is a diagram that allows the identification of the control LED coding:

INDICATOR	RED			GREEN		
			Battery inserted	Battery end of charge		
FIXED	Battery inserted	Battery charging	Battery not	Battery charger waiting for		
			inserted	battery insertion		



## 5.3 Defibrillation PADs

The Geo Saver allows the use of two different defibrillation PADs depending on the patient to be treated:

- Defibrillation PADs for Adults model SAV-C0846
- Defibrillation PADs for Children model SAV-C0016

#### 5.3.1 Defibrillation PADs for Adults SAV-C0846

The SAV-C0846 defibrillation PADs are pre-gelled disposable types.

They must be used on adult patients (**age> 8 years or weight> 25Kg**). Defibrillation PADs are supplied in a single sealed package with the expiration date (typically 30 months). On the expiry date the PADs must be replaced even if not used.

The **SAV-C0846** Pads are characterized by the presence of the cable and the PAD connector **outside the sealed package**. This solution has been adopted in order to maximally speed up the positioning of the Pads avoiding the need to insert the connector during the phases of the rescue.




The **SAV-C0846** PADs are polarized type, that is, the positioning of the electrodes **must not be reversed.** For more information on positioning the defibrillation PADs, refer to the relevant paragraph.

#### 5.3.2 PADs for Children SAV-C0016

The SAV-C0016 defibrillation PADs are pre-gelled disposable types.

They must only be used on children patients (**age** <8 years or weight <25Kg). The defibrillation PADs are supplied in a single sealed package with the expiration date (typically 30 months). On the expiry date the PADs must be replaced even if not used.

The cable, connector and PAD adapter are inside the sealed package.



The PADs SAV-C0016 allow to deliver shocks on pediatric patients with a maximum energy level of 50J as prescribed by the international guidelines ERC/AHA 2017. The PADsSAV-C0016 are polarized type, that is, the positioning of the electrodes **must not be reversed**.

For more information on positioning the defibrillation PADs, refer to the relevant paragraph.




#### 5.3.3 Positioning of defibrillation PADs

The correct placement of the PADs is essential for an efficient analysis of the patient's heart rhythm and for the consequent delivery of the shock (if necessary).

Always refer to the instructions given both on the packaging of the PADs and directly on each individual pad. The PADs of the *Geo Saver* are polarized type; do not reverse the positioning of each single pad.



- 1 Position **Pad 1** immediately below the patient's right collarbone
- 2 Position **Pad 2**on the ribs on the left side of the patient under the left side of the chest



- 1 Position **Pad 1** immediately below the patient's right collarbone
- 2 Position **Pad 2**on the ribs on the left side of the patient under the left side of the chest




## 5.4 Memory Card and USB

The *Geo Saver* allows the recording of data on the **internal memory** as well as on the **external memory card**. Supported memory cards are SD/SDHC cards with capacities up to 8GB



To install a Memory Card in the Geo Saver follow this procedure:

- A. The memory card must be inserted before attaching the battery
- B. Place the device on a firm, stable horizontal shelf as shown in the image



C. Insert the Memory Card with the contacts facing upwards as shown in the image and push it until it is completely inserted

The data recorded directly on the internal memory of the Geo Saver can be downloaded via the **USB port** on the back of the device (image 25).

The USB cable to be used must be a mini USB 2.0 (USB / Mini USB connection)



To connect the mini USB cable to the *Geo Saver* follow this procedure:

- A. Detach the battery and insert the Mini USB terminal of the cable in the appropriate compartment on the Geo Saver
- B. Connect the USB terminal of the cable to a Personal Computer
- C. Use the PC Saver View Express software

#### **!!ATTENTION!!**

The USB is a service port used for device configuration purposes (for the exclusive use of personnel authorized by AMI) or for downloading recorded data stored internally.

The functions related to the USB port are enabled and accessible only when the device is turned off.

WARNING: When the device is switched on, and especially when a patient is connected to it, it is recommended:

- do not use the USB port
- do not touch the USB port

- remove the USB cable, if inserted in the USB port, before starting the device



## 6 Auto test

The **Geo Saver** has been designed to be a totally safe device, always ready for use and able to automatically and constantly verify correct operation, minimizing maintenance operations.

The Geo Saver performs different types of self-tests:

- Activation: Every time a battery is inserted in the device
- Automatically: During Stand-by mode with daily/monthly/half-yearly intervals
- *Switching on:* When the device is switched on

The outcome of the control test can be viewed via a two-color LED (green/red) and the LCD mini-display. The mini-display and the control LED let you know at any time, even when the device is switched off (stand-by mode), the functional status of the device and its battery.

### 6.1 Display and control LED

Both the mini display and the control LED are positioned on the front of the *Geo Saver* keyboard. Based on the different color of the control LED and the information shown on the display, the operator can independently determine the functional status of the defibrillator and its battery.

The following table shows the flashing code of the control LED and the relative screens of the control mini display.

	Control LED green / red bli	nking	
	Device ready for use		
IN STAND-BY (with battery)	Warning for a low battery level, replace it	+	* 🕞
	Faulty device, needs service		
	Device working	OFF	
WORKING	Warning: battery is getting low (5% left)	off	battery is getting low
	Caution! low battery, replace it	● + ★	Iow battery, replace it



## 6.2 ACTIVATION Test

The *Geo Saver* performs functional tests only if the battery is installed. Each time a battery is inserted, the device will perform a diagnostic ACTIVATION test. During this test the device performs a complete control (firmware/hardware), which involves a consumption of the battery equal to a shock, therefore it is advisable, once performed, not to remove the battery from the device. The ACTIVATION test requires a manual intervention by the operator, who must perform the following steps:

#### Insert the battery into the device

If the battery is correctly inserted, the *Geo Saver* will automatically turn on emitting an acoustic signal and the power button (6) will light up green while the control LED will turn off.

The following screens will appear on the control display:



If no error is detected the following screen will be shown on the display:



#### Turn off the device

If it is not to be used immediately turn off the *Geo Saver* and leave the battery inserted to ensure that periodic selfdiagnostic tests are performed (see Section 5.1.3)

#### 6.3 AUTOMATIC Test

The Geo Saver was designed to always be ready in the moment of real need.

The device is equipped with a mode, called stand-by, in which when the device is switched off (with battery installed) it performs diagnostic tests **automatically** on a daily basis.

The automatic self-test does not require any manual operation by the operator and takes a few seconds.

The Geo Saver will inform the operator of the start of the automatic self-test through the mini Control Display:

During the test



after the test



The automatic self-test involves a reasonable consumption of the battery.

Since a daily test with complete analysis would lead to excessive battery consumption, three levels of automatic tests have been set: **basic** (daily), **in-depth** (monthly), **complete** (half-yearly).

The result of the automatic self-test can be verified using the LED and the mini-control display located on the device keyboard.

Consult the Led table and the mini-control display shown in paragraph 6.1



## 6.4 POWER ON Test

The Geo Saver performs self-diagnostic tests each time it is turned on, either from the power button or by inserting the battery.

Following to the battery insertion a diagnostic test of ACTIVATION is performed. This self-test involves a fair amount of energy consumption. It is recommended, once performed, to not remove the battery from the AED.

These tests are performed in order to verify the correct operation of the device before use.

Each test is conducted automatically and lasts a few seconds.

After pressing the power button, (or after inserting the battery) the Geo Saver will emit an acoustic signal to confirm power-up, the control LED will be off and the following screen will be displayed:





If no error is found, the following screen will appear on the display:



From this moment the device will be ready to be used and will provide the operator with the first instructions to start the intervention.

If not to be used immediately, switch off the Geo Saver and leave the battery inserted to ensure periodic self-testing (see Section 6.2).



## 7 Information button 🕡

The Geo Saver is equipped with an "i" button, through which the operator can view various useful information about the device in use on the LCD display.

This button can only be used when the device is switched on and is automatically disabled in the event of an ongoing emergency.

The information shown on the Display is divided into three different pages, which can be consulted by pressing the "i" button *n* times (*n* meaning the number of pages).

Below is a detailed description of the procedure for using this button and the information displayed:

#### > Switch on the device

The Geo Saver will carry out the automatic power on test after which it will be ready for use.

3








#### > Press the "i" button

1. After pressing the button the **first time** the following screen will appear with the related information:





Nr.	Description
1	Device model
I	Device Serial Number
2	Type of supply

2. Pressing the button for the **second time** will display the following screen with the related information:



PROTOCOL:	150-200-200J
SHOCKS:	6
DATE:	01/03/2019

Nr.	Description
3	Pre-set shock protocol
4	Number of shocks made
5	Current date

3. Pressing the button for the **third time** will display the following screen with the related information:



LANGUAGE --> ITALIAN Italian English

Nr.	Description
6	Change language

To change the language, press the "i" button for about 3 seconds and release it. The user will see the following screen:

LANG	UAGE>	ITALIAN	
>	Italian		
	English		

Select the desired language by pressing the "i" button. Once the desired language has been selected, press the "i" button for about 3 seconds to confirm the selection.


The selected language remains in memory and at the next restart of the device it will be the default language.



## 8 Defibrillation

If you need to help a person with sudden cardiac arrest, remember to implement the sequence of actions recommended by ERC and AHA 2017.

The ERC has established a rescue protocol to be respected during the resuscitation of a person suffering from sudden cardiac arrest. This protocol has been called the "chain of life".




- 1 Make sure the person needs help (*unconscious and not breathing and does not shows signs of blood circulation*) and call 118 immediately
- 2 While waiting for a defibrillator to be available, begin CPR maneuvers immediately
- 3 Use the *Geo Saver* defibrillator to restore normal heart rhythm
- 4 Continue until resuscitation of medical competence

### 8.1 Switching on the Geo Saver

The *Geo Saver* defibrillator will automatically start the semi-automatic defibrillation mode every time it is turned on (default setting). Below are the procedures to follow to use the device in this mode.

Press the power button on the device









If the test is successful, the device will suggest the first operation to be performed by the operator using voice (audio) and visual commands (luminous icons and display text):

Voice commands	Display	Luminous Icons Keyboard	
Make the emergency call	call now the emergency service		
Remain calm and follow the voice instructions. If the patient is unconscious and does not breathe, remove clothing in order to apply the electrodes on the bare chest	Remove clothing to expose bare chest	Command Position Defibrillator PADs	
Place the electrodes firmly on the chest as shown in the figure	Place Electrodes firmly to bare chest		



## 8.2 Preparation of the patient


In order to correctly position the defibrillation PADs on the chest, it is necessary to carry out the following preliminary operations:

Remove clothing from the patient's chest

If the patient's chest has thick hair it might be necessary to shave Pads positioning points.

## 8.3 Positioning the PADs


A Remove the defibrillation PADs from their packaging.



**B** Remove the protective film from each individual PAD and place it on the patient's chest



The defibrillation PADs are of the polarized type, this requires that they be positioned at the points indicated on each single PAD. If the patient is a child, use the SAV-C0016 pediatric defibrillation PADs, see the relative paragraph for more information.





# 8.4 Cardiac rhythm analysis

Voice commands	Display	Luminous Icon	s Keyboard
Do not touch the patient			Icon do not touch the patient on with fixed light
Cardiac rhythm analysis in progress	Rhythm Analysis Don't touch patient		Icon type of pads used ( <i>adult / child</i> )

The Geo Saver automatically analyzes the patient's heart rhythm. This phase is highlighted by the following commands:

During cardiac rhythm analysis the patient's body must not be touched and must not be subjected to vibrations or movements. The *Geo Saver* analysis software was designed to recommend defibrillation shock treatment only if the patient is suffering from the following arrhythmias:

Peak to peak Amplitude min. 200 µVolts

interpreted as shockable.

#### **VF** Ventricular Fibrillation

**VT** Ventricular tachycardia (including ventricular flutter and polymorphic ventricular tachycardia)



Rhythm frequency min. 180 bpm and peak-to-peak amplitude min.200 µVolts Some rhythms with very low amplitude or low frequency VT may not be interpreted as shockable.

Some rhythms with very low amplitude or low frequency VF may not be

The **Geo Saver** detects both noise artifacts in the ECG, caused, for example, by patient movement, defibrillation electrode adjustment, and electronic disturbances from external sources. In these cases the analysis is delayed or interrupted.

The Geo Saver is able to detect and filter impulses coming from an implanted pacemaker.

MIN



# 8.5 Shockable rhythm

If a Ventricular Fibrillation or Tachycardia is detected, the Geo Saver will inform the operator using the following commands:

Voice commands	Display	Icons/ Luminous buttons			
Shock recommended	device is charging stay clear patient	Do not touch the patient icon on fixed light			
Keep distance, charging					
Keep distance, the shock will be automatically delivered in 5 (five) seconds		Auto Shock icon flashing in red			
5 seconds countdown starts	IN FIVE SECONDS				

At the end of the countdown the *Geo Saver* will perform the defibrillation shock.

In this phase the AUTO shock indicator will no longer flash and the device will inform the operator using the following commands:

Voice commands	Display			
Shock delivered	SHOCK DELIVERED			

The *Geo Saver* delivers the shock using the BTE waveform with auto compensation of the patient's thoracic impedance. The *Geo Saver* download protocol is incremental, ie the energy delivered to the patient varies incrementally based on the number of shocks performed:

*Geo Saver 200J*: The first shock is delivered to energy of **150J** the following at **200J** *Geo Saver 360J*: The first shock is delivered to energy of **200J** the second at **250J** the following at **360J** 

The detected impedance value must be between 20 and 200 Ohm; if a value outside this range is detected, it is required to position the PADs.

The shock protocol is pre-set, cannot be modified by the user and is reset at each power up.



## 8.6 Change of rhythm

The Geo Saver analyzes the patient's heart rhythm continuously, during the resuscitation phase.

If the device after recommending the shock detects a change in the heart rate of the patient who no longer needs a defibrillation, it will carry out the automatic disarmament. This phase is highlighted by the following commands:

Voice commands	Display			
Shock cancelled	зноск			
Rhythm changed	CANCELLED			

# 8.7 Non-shockable rhythm

If the *Geo Saver* does not detect a VF or a VT during heart rate analysis, it will inform the operator using the following commands:

Shock not recommended

All rhythms other than VF and VT will be considered as non-shockable. For more information, paragraph 10.6.

## 8.8 CPR

The *Geo Saver* defibrillator will guide the operator to CPR (Cardio Pulmonary Resuscitation) in one of the following cases:

- A shockable rhythm was detected and a defibrillation shock was delivered
- A non-shockable rhythm was found
- A shockable rhythm was found but the patient's rhythm changed

The *Geo Saver* will provide instant by instant instructions for performing CPR, instructing the operator on how to perform chest compressions and insufflations. According to the 2017 AHA/ERC guidelines, the duration of cardio-pulmonary resuscitation is about 2 minutes.

If resuscitation is carried out by a single operator, the compressions/insufflations ratio must be 30/2 for 2 minutes (5 cycles) for both adult and child patients.

During the phase of chest compressions the Geo Saver mediates a metronome which will set the rhythm to maintain in order to perform the compressions at the right time. Once the compressions have ended, you will need to perform the two breaths. These instructions are repeated throughout the CPR phase, or about 2 minutes.



The following table shows the main operations to be performed and the relative visual-text-vocal commands provided by *Geo Saver* 

No.	Type of command (Geo Saver)	Instruction Geo Saver	Operations to be performed				
	Vocal	"Begin Cardio-Pulmonary Resuscitation"	<ul> <li>A. Make sure the patient is lying on a flat surface</li> <li>B. Kneel beside the victim</li> <li>C. Place the heel of one hand in the center of the victim's chest</li> <li>D. Place the heel of the other hand over the first one</li> <li>E. Interlace the fingers of both hands and make sure that the</li> </ul>				
1	Visual DISPLAY	cardiopulmunary resuscitation	pressure is not applied to the ribs. Do not exert any pressure on the upper portion of the abdomen or the lower portion of the sternum				
	Visual LUMINOUS ICON	L.					
	Vocal	"Quickly compress the patient's chest"	<b>F.</b> Stand vertically on the victim's chest and, with arms extended, compress the sternum. Keeping the arms stretched, the external cardiac massage is exercised using the weight of the trunk; the oscillation movement must be				
2	Visual DISPLAY	cardiopulmunary resuscitation	<ul> <li>from pivoting on the trank, the oscination movement must be from pivoting on the coxo-femoral joint</li> <li>G. After each compression release all pressure from the chest without losing contact between one's hands and the sternum; repeat the maneuver with a frequency of 100 / min (a little less than 2 compressions per second)</li> <li>H. The compression and release phase must be approximately equal in duration</li> </ul>				
	Visual LUMINOUS ICON						
	Acoustic Signal (BEEP)	The <i>Geo Saver</i> signals with a BEEP every compression to be performed.					
	Vocal	"Perform two breaths" "Exhale" "Exhale"	Immediately open the air passage using the head and chin towards the back maneuver				
3	Visual DISPLAY	cardiopulmunary resuscitation	The rescuer inhales normally and keeping the chin lifted with two fingers, makes the lips adhere around the mouth of the injured person. The contralateral hand closes the nostril to avoid air release and keeps the head in hyperextension. Blow out the air by performing a normal expiration lasting about 1 second.				
	Visual LUMINOUS ICON		1 secondo ognuna				
4	The <i>Geo Saver</i> will r	epeat STEP 1 to 3 for about 2 minutes	Follow the voice and text instructions of the <i>Geo Saver</i> until the device stops the CPR phase (about 2 minutes)				



# 9 Recording, viewing and archiving the data

The *Geo Saver* defibrillator is able to record and store both **the SERVICE data of the device** and **the complete data of the rescue operations** carried out. Data recording and archiving is done automatically (cannot be deactivated by the user) both on **the internal memory** of the device and on **the memory card** when installed.

# 9.1 Data recording

The **internal memory** of the *Geo Saver* allows the storage of up to 6 hours of environmental recordings (audio), ECG tracing, patient data (FC and  $\Omega$ ) and all rescue events. The stored data can be viewed on a PC using the PC Saver View Express software (SAV-C0019).

Two types of files are stored on the external memory SD Card:

- **AED1LOG.txt** This file stores all the automatic self-tests performed by the device with its outcomes and all the **SERVICE** information. This type of file can be viewed on a PC using a simple reading program.
- **AEDFILE.aed** This file stores the rescue data such as: environmental recordings (audio), ECG tracing, patient data (FC and  $\Omega$ ) and all rescue events. This type of file can be redisplayed on a PC using the PC Saver View Express software.

The number and duration of recordings depend on the capacity of the memory card, below is an example:

Туре	Capacity	Stored Data	
	512 MB		1.500 minutes (25 hours)
SD Card	1 GB	Sounds, Events, Parameters, ECG. Service	3.000 minutes (50 hours)
	2 GB	(AED1LOG + AEDFILE)	6.000 minutes (100 hours)
SDHC Card	4 GB		12.000 minutes (200 hours)

# 9.2 Archiving data on PC

The rescue data recorded by the *Geo Saver* defibrillator can be stored, analyzed and printed from a Personal Computer using the management software Saver View Express.





Image 29

For more details on the PC Saver View Express software, consult the relevant user manual.



# 10 Web Management


AMISAVERCLOUD is the platform through which a user can check the status of its Geo Saver.

To access the functions of AMISAVERCLOUD there is a mechanism of authentication with password.

When a Geo Saver is purchased, a new user is generated in AMISAVERCLOUD by referring to an e-mail provided by the customer. When the new account is created, the system automatically sends the login credentials with an invitation to change the password at the time of the first login to secure the data relating to the Geo Saver.

To access your account, go to the page:

### www.amisavercloud.com



Click on the button "Login" and enter your credentials to enter your account.

SaverClaud x		Alterio III.
← → C ff 🗋 savercloud.stg.sl14	.com/users/sign_in	<b>☆</b> =
	🏂 ami italia	Q Map
	Email	
	Password	
	Languaga .	
	Bumamber ma	
	Forgot your password?	
	A.M.L. ITALIA S.R.L. © 2017, ALL RIGHT RESERVED: P. WA 07291540636	



## **10.1 Main features**

## **10.1.1 Changing the language**


AMISAVERCLOUD is a multilingual cloud service. You can select one of the languages available through the specific icon on the top right.

Saver		٣	-0
Dealer		LT Hinton	1
and have see C.F.	 State of the second sec	10 trafich of	
0005201810.03	 Fight and find the second	11 talara	

## 10.1.2 User profile and password

The current user has the possibility to view his profile and modify the password via the links located on the menu.

Saver	Q
Dealer Oktributive 1 *	
Change password	
Profile	
Logout	
USERS	





## **10.1.3 Device management**

Each user can be associated with one or more Geo Savers. These are listed under the "DEVICES" menu item and displayed on a map that briefly summarizes their status.

Saver	2.00 C								E.
Dealler Derifikation Inder 1 + D7705/2019, 12:00	GEOSAVERS Manager pounds and pour counts Gard	Samers							Home - David
DASHBOARD	Filter								Denter and a second
USERS	in Saver SN	Geoloc SN	Owner						ting a state of the state of the
DEVICES	430.0004101700701	10044210480014	T Dasher	ø			1		and the second with second
	455/1031411700035	16044216480168	T Dealer	0	٠	0	1		terral Contraction of the second seco
35 ami italia	<ul> <li>400000011700002</li> </ul>	169442121281331	T SubDealert			0			Anger Inger Anger
kepest hetigi? Eliofo@wehitsika.com	45502000111100004	10044216-00753	Theater	o	٠	0	1		California Constantion (14)
	4054024111700003	10044315480225	T Cherrentiti	٥		8			frater and
	32570033881400009	18/0442177120140	T Dealer						and the second
	Mass entige to user.							×	and an and and
									andre Lader

It is possible to view the details of each device by following the link in the table (or inside the map) for each of them.

When viewing a Geo Saver detail, the menu is expanded with the following items:

- Geo Saver: summary page details
- Saver Log: list of logs received from the Saver
- Geoloc Log: list of logs received from the Geoloc
- ECG Streaming List (if data is present): list of ECG streaming files and possibility to download or reproduce each of them.
- GPS tracks (if data is present): list of GPS tracks recorded by Geo Saver and display of each of these on a map
- Maintenance: management of accessories duration (Geoloc battery, pads)
- Alarms configuration: configuration of the recipients to whom the alarm messages are to be sent (via SMS or e-mail).






## 10.1.4 ECG Streaming

To activate the ECG transmission, switch on the Geo Saver and then enable ECG transmission. While the ECG is streaming from the Geo Saver, a notification is displayed on the cloud and the "STREAMING" section becomes accessible as a "GEO SAVER" sub-level of the menu.

The device in the ECG check phase is highlighted in the Geo Saver table and a link to the section appears on the same page. In this section, it is possible to view the streaming in real time.

At the end of the ECG control phase the transmitted data are saved and becomes available for review in the "ECG STREAM HISTORY " section.









## 10.1.5 Auto tracking

Among the command that can be sent to the Geo Saver through the cloud there's enable/disable Auto tracking. This functionality can be found in the GEOSAVER page –GEOLOC section.


When this function is active the Geo Saver, after having detected a movement, will start sending its positions to the cloud. After few minutes from the last move, the file with the path becomes available in the "GPS TRACKS" section accessible from the Geo Saver page as a menu sub-level.





### **10.1.6 Battery replacement**

Follow the instructions in paragraph 5.2.6 to replace the Geoloc battery. Once completed, go to the AMISAVERCLOUD and, from the MAINTENANCE page of the device in possession, follow the instructions below.





## 10.1.7 Firmware update

If AMI Italia makes new firmware available, the user is notified with an icon on the device table.

If a device has a less recent version of the firmware than the last one released on the line corresponding to the Geo Saver in question, an icon will be displayed, by clicking that you are taken to the device page. There the user can see which component needs an update: an icon the same as the one on the table is displayed next to the serial number of the device to be updated.


The update process begins with sending the command to the device: click on the aforementioned icon and follow the proposed steps.

								And Statement
= Saver SN		Geoloc SN	Owner					water the second second
211500516	101		T Amitala		0 1	8		Carlo and a second
• 123402340	23492.0		Y Amirala		0 3	-	2	
Cas				_	_		_	
Saver	=							
Advent	GEOSAL" Here you in Contain Uber	Update	Saver firmware	Ê				ng sale aber 01, 2022 @
-400404		New upda	te available					E) Geoloc
- MANUELLINE BADILINE SIDE - SPETIMENT	Cumha	Calmon agricula		3	hear ann an APA 25	0k		17120124
- NUMBER	0.000							
YWUMBATE					-			B. 10 B.
ALASMS CONTIN					0	WC Battery	level .	and the second



# **10.2 Dashboard**

After logging in to the cloud you are redirected to the Dashboard. In this page there is a map with all Geo Savers devices -linked to the current users- located through a coloured icon. The colour of the icon is representative of the state of the Geo Saver. Clicking one of these icons a small window appears with some of the main information related to that specific device.





# **10.3 Devices**

In the section dedicated to the Devices, all the devices to which the current user has access are shown in a paged table. These devices can be filtered by:

- Membership user
- Range of serial numbers of the Saver
- Range of serial numbers of the Geoloc
- Geographic area

From the table it is possible to have quick access to some sections / actions by:

- 1. Link to the page dedicated to the specific Geo Saver
- 2. Icon that notifies the presence of a new release (for at least one of the components Saver, Geoloc, radio)
- 3. Link to the section that lists Complete Logs received from Geo Saver (where present)
- 4. Link to the section that lists the history of ECG streaming received from Geo Saver (where present)

USERS	100	Saver SN	Geoloc SN	Owner							
DEVICES		21/SO0516001		Y Amiltalla			0	٤	۵		8
		12341234123412		▼ Amiitalia			0	2			8
	٠	175A003041500021	1604A216480004	▼ Amiitalia	0		0	٨	Ð	۲	8
	0	455A005111600061	1604A216410215	▼ Asd Volley Sport			0	٤			
	٠	455A005111600062	1604A216410001	T GeoSaver Demo	0		0	*		۲	
	۲	925P004121600001	1604A216410230	▼ Anvitalia		4	0	*	12	•	8
	3	375P003091700001	1604A216410006	▼ Amiitalia	0		0	2	1	1	8
	3	185P003051700001	1604A216410231	▼ Amiitalia			0	*		1	8
						/		ſ			1
					1/				3		4



# 10.4 Geo Saver

The section dedicated to the specific Geo Saver can be divided into three parts

- At the top enabling / disabling of alarms
- On the left everything related to the Saver
- On the right everything related to the Geoloc (concealed)

In the area relating to the Saver we can distinguish:

- 1. Collapsible panel for sending a command
- 2. Collapsible panel with the last commands sent and relative completion status
- 3. Collapsible panel with the details of the last log received or Code of the last error
- 4. Code of the last warning (if present)
- 5. Pie chart with battery level
- 6. Collapsible panel with the last set of configurations

In the area relating to the Geoloc we can distinguish:

- 7. Collapsible panel for sending a command
- 8. Collapsible panel with the last commands sent and relative completion status
- 9. Collapsible panel with the details of the last log received or Code of the last error
- 10. Map showing the last position received or Pie chart with battery level
- 11. Collapsible panel with the last set of configurations

Admin +	GEOSAVER Intergratemanage your Darchweit and für components		Home - Druptelpe - GertSaver con the Saver 455-4031110000
DAL-BOARD USTRS	Gener (You) User Adrun	Alarmy not fications Ernal Insperts East Institute Self-Insperts Ensemble Movement	e Besteur pain repiring Sate 14 giugno 2018 •
*ETOLAH8 - 14499 104	Saver - 455400511160	0062 🛓 🔪	Geoloc - 16044216410001 📩
- 100000004 - 07570400	Command Landar	A Consumbus	da 7> v
· BLARMS CONTLE	i, lent communits 2	w #3 Battery level #3 Battery level	A CONTRACTOR OF A
	o Later big hels any sense	Tumuutuu 5 13 223	
		Configuration	antı 8



# 10.5 Saver Log

The section dedicated to logs received from the Saver presents a list of logs that can be expanded by clicking on them with the mouse.

On the left side of the page there is a box where it is possible to filter the list of logs arrived by arrival date. An additional filter can be added selecting only the logs with errors and / or warnings.

Saver			
Dealer Distributor fevel 1 + 07/05/2019 12:26	SAVER LOG HISTORY View and filter saver log history		
DASHBOARD	Filter	^	O MAY 07, 2019 03:01
USERS	From		O MAY 06, 2019 10:48
Users	Date	8	0 MAY 06, 2019 03:00
DEVICES	То		O MAY 05, 2019 03:01
GEOSAVER	Date		0 MAY 04, 2019 03:01
- SAVER LOG	Only with errors		0 MAY 03, 2019 03:01
- GEOLOC LOG			O MAY 02, 2019 03:01
- ECG STREAM HISTORY	Only with warnings		0 MAY 01, 2019 03:01
- GPS TRACKS	1 2 3 Next Last>>		O APRIL 30, 2019 03:01
- MAINTENANCE			O APRIL 29, 2019 14:15
- ALARMS CONFIG			O APRIL 29, 2019 14:14
Need help?			O APRIL 29, 2019 13:22
Sinfo@amiitalia.com			O APRIL 29, 2019 11:25
			O APRIL 29, 2019 11:19
			O APRIL 29, 2019 11:17



# 10.6 Geoloc Log

The section dedicated to logs received from the Geoloc presents a list of logs received which can be expanded by clicking on them with the mouse.

On the left side of the page there is a box where it is possible to filter the list of logs arrived by arrival date. An additional filter can be added by selecting only the logs with errors. There is also a map showing the position of the selected log or the last positions.

Saver	=		
Dealer Statrizet wert = 07/05/2019 12:28	GEOLOG LOG HISTORY View and filter geoloc log history		
DASHBOARD	Filter	^	O MAY 07, 2019 03:01
USERS	From		O MAY 06, 2019 10:48
vacha -	Date		O MAY 06, 2019 03:00
DEVICES	То		O MAY 05, 2019 03:01
- GEDSAVER	Date		O MAY 04, 2019 03:01
- SAVER LOG	Only with errors		O MAY 03, 2019 03:01
- 680LOC LOG			O MAY 02, 2019 03:01
- ECG STREAM HISTORY	1 2 3 _ Next	Last >>	O MAY 01, 2019 03:01
- GPS TRACKS	To all		O APRIL 30, 2019 03:01
- MAINTENANCE			O APRIL 29, 2019 14:15
- ALARMS CONFIG		111110	O APRIL 29, 2019 14:14
Sami.italia	•	//////	O APRIL 29, 2019 13:22
steed neip?		//////	O APRIL 29, 2019 13:14
		11818	O APRIL 29, 2019 11:25
		1111	O APRIL 29, 2019 11:19



# **10.7 Streaming**

During the streaming phase of a Geo Saver the link to this section will become visible, presenting:

- A graph showing the streaming in real time
- Some relevant data on the current stream
- The GPS position on a map

During the streaming, a Growl notification is also presented with the link to this section and a red panel on the Geo Saver page.





# 10.8 List of saved ECG Streaming

The section dedicated to the list of ECG streams for the specific Geo Saver is made visible only in the presence of at least one file and presents:

- A graph to playback the streaming
- A filter from which to select the date of interest
- A table with the list of streaming resulting from application of the filter. From it you can start / stop playback or download the file.

ECG STREAM HISTORY Dat of saver aquived ECG streams Home + Devices + GooSaver with Saver SN 4350004101700051 + ECG Stream History

Date		Filename	Acquired on	Duration		_	_
Date	<b>#</b>	2019-04-23_174331_#350004101700051.atream	April 23, 2019 17:46	00:03:35:396	P	۲	
		2019-03-26_180942_4350004101790051.stream	March 26, 2019 18:10	02:01:02.963	φ	٠	
		2019-02-21_145848_4350004101700051.stream	February 21, 2019 1459	00:01:03:398	ø	۲	30
		2018-11-09_122751_4350004101700051.atmam	November 09, 2018 12:29	02:00:39.078	Ð	٠	à
		2018-11-08_164536_4350004101700051.stream	November 00, 2018 16:45	00:00:43.853	ø	٠	\$



# **10.9 Tracks**

The section dedicated to the saved tracks for the specific Geo Saver is made visible only in the presence of at least one file and presents:

- A map
- A filter to select the set of dates of interest
- A table with the list of tracks resulting from the application of the filter. By selecting one of these it is possible to view its layout on the map above.

	nuese a la l	7.8	A	and the state of the state		Ľ.
	West .	· 6		·	3.50	1
· · ·		- The	1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	and the second sec	
	- sumo -	en.	A. : A		20	1
1	Antenger a	Ever. 1	Nummers -	CUL.		
		12 11.4		the first and		ł
Anteriariadale	- the	1	STAL AND I DE	And in	1.0	
		the second by	mar in Stall	1. 1. 1.		
the second second	10		A A A A A A A A A A A A A A A A A A A	a second s		
March 1	Ta	a. L. S	N. 59			
	ta Domg	No.	N 83	1 Art	S.	
No.	tai Comg	X	e S	K		A LUXAN
	ter	N		A		ALL DATES
				1		ALL AND A
	and the second sec		Carl		brianner m	L'AND SALES
	En Double of	N. S.			Driamper participation	List and a second
Filter	a contraction of the second	Name	Filmers	Acquired on	Pranya-	A LAND IN A
	Ter Donne a	Name 2019-05-10,131004	Filenams	(Aug	iriamae)	a la state a state
From				Acquired on	.0	0 0
Diffe	te constant	2019-05-10, 191004	16946217120124_20190510_150056.gps	Acquired on May 10, 2010 1540	.0	0 0 0
From		2019-05-10,131004 2019-05-10,145708	16944217120124_20190510_150356 gpx	Acquired on May 10, 2019 15:00 May 10, 2019 15:00	.0	0 0 0 0





# 11 Maintenance

The *Geo Saver* defibrillator was designed to make maintenance operations as simple and autonomous as possible. In fact, thanks to the control tests carried out in total autonomy by the device, it is not necessary to perform any

extraordinary maintenance, but only routine maintenance which consists of a frequent visual check of the LED and the control display, together with a visual inspection of the relative accessories.

Alternatively, you can consult AMISAVERCLOUD in the GEO SAVER section to check the operating status or enabling the alarms to be automatically sent if a malfunction occurs.

Whenever it is necessary to contact the supplier for assistance during an installation, or to report anomalies, contact the supplier using the references:

Assistance request	email:	<u>info@amiitalia.com</u>
	Phone:	+39 081 806 05 74
	Website:	www.amiitalia.com

## 11.1 After each use

After using the *Geo Saver* defibrillator it is necessary to proceed with the following operations in order to prepare the device for the next use:

- 1. Check the presence of the memory card and its remaining capacity (see paragraph 4.4 e 5.4)
- 2. Check that the control LED is on with flashing lighting (flashing green)
- 3. If they have been used, replace the PADs with a new package
- 4. If not used, check the expiry date of the PADs, if expired replace them with a new package

# **11.2 Ordinary maintenance**

Thanks to the control tests carried out in total autonomy by *Geo Saver*, ordinary maintenance will require a simple and quick inspection, following the operations described in the table:

Check Daily	Check Monthly	Check before use	Check after use	Action indicated
*		*	*	Check the LED and the control display.
*		*	*	Check the integrity of the device, its parts and the accessories supplied.
	*	*		Check the expiration date of the defibrillation PADs.
		*	*	Check the remaining capacity of the memory card.

	CONTRO	DLLED	PADSEX	PIRATION	DEVICE	
Date	Is flashing on	ly in green?	is the date	still valid?	Visual inspection	Signature
	Y	N	Y	Ν	ok	
	Y	N	Y	N	ok	
	Y	N	Y	N	ok	
	Y	N	Y	N	ok	
	Y	N	Y	N	ok	
	Y	N	Y	N	ok	
	Y	N	Y	N	ok	
	Y	N	Y	N	ok	



# **11.3 Cleaning**

The structure of the *Geo Saver* defibrillator, including the connection port of the defibrillation electrodes, can be sanitized using a soft cloth dampened with one of the cleaning solutions listed below:

- a) Isopropyl alcohol (70% solution)
- b) Soap water
- c) Bleach (30 ml per liter of water)
- d) Detergents containing ammonia
- e) Detergents containing glutaraldehyde
- f) Oxygenated water



Do not immerse the *Geo Saver* in any liquid.

Do not use abrasive materials or detergents, strong solvents such as acetone or acetone-based detergents, and enzymatic detergents. Do not sterilize the *Geo Saver* or its accessories.

## **11.4 Preservation**

The *Geo Saver* must be stored in a place where the environmental and safety conditions indicated in the table below are observed according to the temperature and humidity indicated in the chapter 12.2. If installed it is advisable to keep the device with the battery always inserted to allow it to carry out periodic self-diagnostic tests. For easy retrieval of the device in case of emergency, place it in easily accessible place and faced in a way that the control LEDs are clearly visible.

Do not use, install or store the <i>Geo Saver</i> in conditions of temperature or humidity that exceed the ranges indicated in this user manual.		Do not install or store the <i>Geo</i> <i>Saver</i> in areas directly exposed to sunlight.
Do not install or store the <i>Geo Saver</i> in areas subjected to sudden changes in temperature or humidity.		Do not install or store the <i>Geo Saver</i> near heat sources.
Do not use, install or store the <i>Geo Saver</i> in places subjected to strong vibrations.		Do not use, install or store the <i>Geo Saver</i> in environments with high concentrations of flammable gases or anesthetics.
Do not install or store the <i>Geo Saver</i> in areas with a high concentration of dust.	OO Th	The <i>Geo Saver</i> must be opened for maintenance only by A.M.I. Italia srl or by personnel authorized by the same.



# **11.5 Troubleshooting Guide**

The following table lists the symptoms, the possible causes and the possible corrective actions of the problems that may arise. For more information on the implementation of corrective actions, refer to the other sections of the user's manual. If the failure of the unit persists, request assistance.

Symptom	LED	Mini display	Possible cause	Corrective action
Device with battery installed does not switch on, the LED and the control display are both off.	OFF	OFF	The battery is totally discharged or faulty The device does not work	Try replacing the battery. If the problem persists, call for assistance Ask for assistance
In <b>standby</b> the control LED flashes green but the mini Display is off	۲	OFF	The mini display is broken	Contact the assistance center
In <b>standby</b> the control LED is off but a "V" appears on the control mini-display.	OFF		The control LED is broken	Contact the assistance center
In <b>standby</b> the control LED flashes RED and a wrench appears on the control display.			During the daily self-test a critical error of the device was found	Contact a service center and report the error code.
In <b>standby</b> the control LED flashes GREEN / RED alternately and a wrench appears on the control display.		*	Very low battery Level <1% The device may turn off during use. (see the relevant paragraph)	Replace the battery
In the <b>operating mode</b> the voice command "Low battery" is issued.	<b>()</b> OFF		Low battery. 5% battery level. It is possible to use the device but the battery level is low ( <i>see the relevant paragraph</i> )	Get a new battery and replace it as soon as possible.
During normal use the voice command "Battery low, Replace"	<b>1</b>	* 🕞	The battery is depleted. Level <1% The device may turn off during use. (see the relevant paragraph)	Avoid using the device if possible. Replace the battery
			The PADs connector has not been inserted correctly or it has been removed	Insert the PADs connector in the appropriate compartment
With the device turned on and after placing the PADs on the patient, the device continues to communicate:	OFF	<b>√</b> □□□}	The PADs have been placed incorrectly	Correctly position the PADs on the patient's stripped chest. If necessary, remove the hair from the chest with a razor
"Place electrodes"			PADs are not working properly	Check the integrity and expiration of the PADs, replace them if necessary
The device turns on, the mini is on but no voice command is issued	OFF		The device's speaker does not work	Ask for assistance



# **12 Technical specifications**

The technical specifications of the Geo Saver defibrillator, its parts and accessories are shown below.

# **12.1 Physical characteristics**

Category	Nominal specifications				
Dimensions	29,5 x 23,0 x 11,5 cm				
	With battery <b>Li-SOCl</b> <sub>2</sub> (SAV-C1032):	2,54 Kg + Adult Pad (2,63 Kg)			
Weight	With battery <b>Li-Ion</b> (SAV-C1033):	2,57 Kg + Adult Pad (2,66 Kg)			

# **12.2 Environmental requirements**

Category		Nominal specifications			
Temperature	Operational and standby:	0 a 55°C (32 a 131°F)			
	Storage and transport:	-40 a 70°C (-40 a 158°F)			
Relative humidity	Operational and standby:	10% a 95% (without condensation)			
	Storage and transport:	without humidity control (from $-40^{\circ}$ C to $+5^{\circ}$ C)			
		up to 90% (from $+ 5 \circ C$ to $+35 \circ C$ )			
		with water vapor up to 50 hPa (from>35°C to +70°C)			
Atmospheric pressure	Operating conditions:	620 hPa at 1060 hPa			
Atmospheric pressure	operating conditions.	(altitude calculated min -382 mt and max 3955 mt)			
Operating functional	Normal use:	Keep the AED device within the operating and standby ranges (not			
conditions		the storage and transport ranges) so that the device is ready for use.			
		When starting from the inoperative conditions, let the device			
		stabilize at the operating conditions for at least 2 hours, before the			
	normal use.				
Tolerance to impacts and	Complies with IEC/EN	60601-1 clause 21 (mechanical forces)			
falls					
Sealing system	Complies with IEC/EN 60529 class IP56 standards; anti-spray, dustproof (with battery installed)				
ESD (electrostatic shock)	Complies with IEC/EN 61000-4-2:2002 (3), Security level 4				
EMC emissions / immunity	See chapter 13				
Radio Equipment Directive	Directive 2014/53/UE				

# **12.3 Reference regulations**

<b>Regulations and Directives</b>	DIRECTIVE 2007/47/CE
	IEC/EN 60601-1
	IEC/EN 60601-1-2
	IEC/EN 60601-1-4
	IEC/EN 60601-1-6
	IEC/EN 60601-1-8
	IEC/EN 60601-1-11
	IEC/EN 60601-1-12
	IEC/EN 60601-2-4
	IEC/EN 60086-4
	IEC/EN 60529
	DIRECTIVE 2014/53/UE – RED
	ETSI EN 301 489-1, 7, 19, 52



# 12.4 Alarms table

Priority	Cause	Visual signal
HIGH	Device ready to deliver the shock	LED Shock Icon flashing
HIGH	Low battery (<1% capacity)	Control LED flashing

# **12.5 Controls and indicators**

Category	Nominal specifications		
Buttons	ON / OFF button (device switching on and off)		
Buttons	"i" button INFORMATION		
	Mini Display LCD control of device status		
	Device status control LED (bicolor RED / GREEN)		
	• LED to place defibrillation PADs (2 LED Red)		
	• LED do not touch patient (2 LED Red)		
Visual Indicators	• LED it is possible to touch patient (1 LED Red)		
	• LED adult patient (1 LED Green)		
	• LED pediatric patient (1 LED Green)		
	LED ON/OFF button (2 LED Green)		
	LED shock indicator AUTO (8 LED Red)		
Multilingual voices for instructions during use of the device			
Sound Indicators	Acoustic signals of warnings and dangers		
Smaalaan	Pre-set Volume (Emissions in compliance with IEC/EN 60601-2-4 point 6.1)		
Speaker	Min. Variation 20% max 100% (60 dBA to 80 dBA ±3 dBA)		
Microphone	Recording automatically activated when device is switched on		
Streaming	ON / OFF setting from menu for sending ECG data to remote		

# 12.6 Data memory

Category	Nominal specifications			
Internal Memory Capacity	6 hours of environ	6 hours of environmental audio recording, ECG tracing and events		
External memory (optional)	External SD / SDI	External SD / SDHC memory cards up to 8GB		
Archived data	AED1LOG.txt	Daily self-tests, Errors found, Device usage data, Device information		
Archived data	AEDFILE.aed	Rescue events, voices and environmental noises, ECG tracing of rescue, Vital parameters of the patient analysed and detected by the Geo Saver		
Data display	Via PC Saver View Express software (Microsoft Windows compatible)			



# 12.7 Defibrillator

Category		Nominal specifications		
Waveform	<b>Biphasic Truncated Exponential (BTE)</b> The waveform parameters are automatically adjusted according to the patient's impedance. In the graph on the left $t_{pos}$ represents the duration of phase 1 (ms), $t_{neg}$ represents the duration of phase 2 (ms), $t_{int}$ is the delay between phases, $U_{max}$ indicates the peak voltage, $t_{imp}$ is the final voltage. In order to compensate for variations in the patient's impedance, the duration of each phase of the waveform is dynamically adjusted based on the charge delivered, as indicated in the paragraph following.			
Energy delivered (max)	Version 200J:	200J nominal with a charge from 50 $\Omega$		
(Adults)	Version 360J:	350J nominal with a charge from 50 $\Omega$		
Shock protocol	Version 200J:	Incremental: First: 150J – Subsequent: 200J		
(Adults)	Version 360J:	Incremental: First: 200J - Second: 250J - Subsequent: 350J		
Energy delivered (max)	Version 200J:	50 J nominal with a charge of 50 $\Omega$		
(Children)	Version 360J:	(when using defibrillation PADs SAV-C0016)		
Shock protocol	Version 200J:	Fixed: First and Subsequent: 50J		
(Children)	Version 360J:	-		
Charge control	Automatic through patient analysis system			
Charge time	<i>Version 200J:</i> $\leq 9 \text{ sec (according to IEC/EN 60601-2-4 §6.8.2 (7a)) (new fully charged battery)}$			
(from the shock notice)	<i>Version 360J:</i> $\leq 15 \text{ sec}$ (according to IEC/EN 60601-2-4 §6.8.2 (7a)) (new fully charged battery)			
Charge time	Version 200J:	$\leq$ 15 sec (according to IEC/EN 60601-2-4 §6.8.2 (8a)) (new fully charged battery)		
(from the beginning of the	Version 360J:	$\leq 21$ sec (according to IEC/EN 60601-2-4 §6.8.2 (8a)) (new fully charged battery)		
analysis)				
Indication charge completed	SHOCK Icon fla			
• Voice Cor		"The shock will be delivered in 5 seconds", then starts one beep per second		
Shock delivery	The shock is delivered automatically, after the 5 seconds			
Disarmament	Automatic: Manual:	<ul> <li>If the patient's analysis system considers the rhythm no longer shockable, or</li> <li>If defibrillation PADs have been removed from the patient or disconnected from the unit.</li> <li>If the operator presses the OFF / DEACTIVATE button at any time to deactivate or switch off the appliance.</li> </ul>		
Shock detection vector	Through the defibrillation PADs (Lead II)			
Isolation of the patient	Type BF			
isolation of the patient	1 JPC DI			



# 12.8 Efficiency of delivered energy

Impedance	Shock of 50 J (Paediatric)       Tpos     Tneg     Umax       (ms)     (Ms)     (A)     Set Energy (J)				Energy delivered (Joules)
25 Ohm	6,8	3,3	18,6	50	50,2
50 Ohm	7,2	3	12,3	50	49,2
75 Ohm	7,4	2,8	9,6	50	48,6
100 Ohm	7,5	2,7	8,1	50	48,4
125 Ohm	7,6	2,6	7,1	50	48,75
150 Ohm	7,7	2,5	6,4	50	48
175 Ohm	7,7	2,4	5,8	50	48,3


Impedance	Tpos (ms)	Shock of 2 Tneg (ms)	150 J U <sub>max</sub> (A)	Set Energy (J)	Energy delivered (Joules)
25 Ohm	4,6	5,6	43,8	150	147,2
50 Ohm	6,2	4	24,9	150	146,9
75 Ohm	6,8	3,3	18,4	150	147,15
100 Ohm	7,2	3	15	150	147,2
125 Ohm	7,4	2,8	13	150	146,5
150 Ohm	7,5	2,7	11,5	150	147
175 Ohm	7,6	2,6	10,4	150	147

Impedance	<b>Tpos</b> (ms)	Shock of Tneg (ms)	200 J U <sub>max</sub> (A)	Set Energy (J)	Energy delivered (Joules)
25 Ohm	4,6	5,6	57,6	200	197,2
50 Ohm	6,1	4	28,8	200	196
75 Ohm	6,8	3,3	15,9	200	196,2
100 Ohm	7,2	3	17,3	200	196
125 Ohm	7,4	2,8	14,9	200	195,5
150 Ohm	7,5	2,7	13,2	200	195,3
175 Ohm	8,5	3	11,4	200	193,55



Impedance	Tpos (ms)	Shock of Tneg (ms)	250 J U <sub>max</sub> (A)	Set Energy (J)	Energy delivered (Joules)
25 Ohm	4,6	5,6	56,6	250	246,4
50 Ohm	6,2	4	32,3	250	246,8
75 Ohm	6,8	3,3	23,7	250	244,95
100 Ohm	7,2	3	19,4	250	244,8
125 Ohm	8,4	3,4	15,8	250	241,75
150 Ohm	10	4	13,3	250	242,4
175 Ohm	11,5	4,6	11,4	250	241,15

Impedance	Shock of 350 J Tpos Tneg Umax				Energy delivered
	(ms)	(ms)	U <sub>max</sub> (A)	Set Energy (J)	(Joules)
25 Ohm	4,9	9,4	65,2	350	336
50 Ohm	7,2	6	36,6	350	341
75 Ohm	9,5	6,9	25,4	350	339,3
100 Ohm	12	8,2	19,4	350	339
125 Ohm	14,4	9,5	15,8	350	338,5
150 Ohm	16,9	10,9	13,3	350	339
175 Ohm	18,9	11,5	11,4	350	331,8



Efficiency of the energy supplied graph



# 12.9 Patient analysis system

Category	Nominal specifications
Function	Determines the patient's impedance and evaluates the ECG rhythm and signal quality to
Function	determine whether or not the shock delivery is appropriate.
Impedance range	20 - 200 Ω
ECG analysis time	≥4 seconds (with new fully charged battery) respecting IEC/EN 60601-2-4
Sensibility	97% Respects the guidelines IEC/EN 60601-2-4 2002(3) sources AHADB, MITDB and EDB
Specificity	99% Respects the guidelines IEC/EN 60601-2-4 2002(3) sources AHADB, MITDB and EDB
Shockable rhythms	If used on a patient who has the characteristics listed in the usage criteria, the <i>Geo Saver</i> defibrillator is designed to recommend a defibrillating shock when it detects the right impedance and when the following situations occur: <b>Ventricular Fibrillation</b> peak-to-peak amplitude at least 200µVolts <b>Ventricular Tachycardia</b> with cardiac rhythm frequency min. 180 bpm and peak-to-peak amplitude at least 200µVolts (including ventricular flutter and polymorphic ventricular tachycardia)
Non-shockable rhythms	The <i>Geo Saver</i> is designed to not recommend shocks with all other rhythms, including: normal sinusoidal rhythm, moderate ventricular fibrillation ( $<200 \mu$ Volts), some slow ventricular tachycardia and asystoles.

# 12.10 ECG Analysis Function

ECG rhythm	Dimension Test sample	Objective	Detected value
Shockable rhythm Ventricular Fibrillation (VF)	500	Sensibility > 90%	98%
Shockable rhythm Ventricular Tachycardia (VT, bpm>140)	600	Sensibility > 75%	92%
Non-shockable rhythm Normal sinusal rhythm	1500	Specificity > 99%	100%
Non-shockable rhythm Asystole	30	Specificity > 95%	100%
Untreatable rhythm generic AF, SVT, PVC	30	Specificity > 95%	100%
Positive predictive values			97.1%
False positives			4.1%

# 12.11 Non rechargeable battery

Category	Nominal specifications			
REF (Model)	SAV-C1032	SAV-C1032		
Туре	Li-SOCl <sub>2</sub> (lithium	Li-SOCl <sub>2</sub> (lithium-thionyl chloride) disposable, non-rechargeable		
Voltage	28,8 VDC - 3500 mAh			
Microphone	Active if memory card is installed to record voices and environmental noises			
Capacity	Standard 200J 300 cycles of complete rescues (shocks at 200J. and CPR) *			
	<i>Power 360J</i> 200 cycles of complete rescues (shocks at 360J. and CPR) *			
	ECG analysis 35 continuous hours*			
Duration in Standby	4 years if installed in the AED, assuming an activation test, daily self-tests without turning on			
(installed battery)	the AED*			

\* New and fully charged battery at a constant temperature of 20°C and relative humidity without condensation 45%

12.13



# 12.12 Rechargeable battery

Category	Nominal specifi	Nominal specifications		
REF (Model)	SAV-C1033			
Туре	Li ion (lithium ior	Li ion (lithium ions) Rechargeable		
Voltage	21,6 VDC - 2100	21,6 VDC - 2100 mAh		
Capacity	Standard 200J	Standard 200J 250 continuous shocks*		
	Power 360J	<i>Power 360J</i> 160 continuous shocks *		
	ECG analysis	ECG analysis 21 continuous hours*		
Charging time	$\leq$ 2,5 hours with c	$\leq$ 2,5 hours with charging station SAV-C1035*		
Shelf Life	2 years or 300 cha	2 years or 300 charge/shock cycles (the one that occurs first) *		
* New and fully charged battery at a constant temperature of 20°C and relative humidity without condensation 45%				

Internal back-up battery

# Category Nominal specifications Type Battery Coin Cell (LiMnO2) Purpose Maintaining configuration data (date / time, etc) Voltage 3 VDC Duration Maintains data for 3 years (without external battery) Maintains data for 6 years (with external battery inserted within 12 months)

# 12.14 Rechargeable battery charger

Category	Nominal specifications			
REF (Model)	SAV-C1035			
Charge control	LED multicolor red green (see paragraph 4.2.1)			
	Input	Input 15Vdc-2.67A / 12Vdc-5.5A		
Power supply	Output	26VDC - 1,5A		
	Absorption	40W/66W		
	Model	MeanWell GS40A15-P1J		
	Identification code	SAV-C0013		
AC/DC Adapter	Input	100-240VAC - 50/60Hz - 1.5A		
	Output	15V - 2.67A		
	Absorption	40W		

# 12.15 Defibrillation PADs

Category	ADULTS	CHILDREN	
REF (Model)	SAV-C0846	SAV-C0016	
Series	Cable and connector outside the envelope	Cable PADs and connector inside the envelope	
Patient range	Adults age >8 years or weight > 25Kg	Children age 1 - 8 years or weight < 25Kg	
Intended use	Dispo	osable	
No. of shocks tolerated	50 shocks at 360J		
Support material	Medical FOAM, thickness 1 mm		
Conductive gel	Low impedance conductive adhesive gel		
Total area (for pad)	136 cm <sup>2</sup> 75 cm <sup>2</sup>		
Active area (for pad)	94 cm <sup>2</sup> 40 cm <sup>2</sup>		
Conductive material	Metal foil		
Connection	Anti-shock safety connector		
Cable length	120 cm (normally)		



# 12.16 Timing of Shock cycles

Charging time performance in accordance with 60601-2-4 (201.101)	Specific	Result
The maximum time between the beginning of the ECG rhythm analysis and the completion of the charge at maximum energy	< 30 seconds	OK
The maximum time from turn on to completion of the charge at maximum energy	< 40 seconds	OK

# 12.17 Geoloc Module

Geoloc Module				
Frequency         GSM: 850, 900, 1800, 1900 MHz;           UMTS: 900, 2100 MHz				
Performance	GPS: 1575, 1600 MHZ         • Geo-location (geographical position of the device in real time)         • Remote control (tracking, anti-theft and device configuration)         • Telemetry (real-time acquisition of device status, parameters and alarms)         • Remote assistance (real-time phone call and ECG data streaming)			

# 12.18 Geoloc Module Battery Type

	Geoloc Module Battery Type			
Туре	Li-SOCl <sub>2</sub> disposarle code SAV-C1038			
Autonomy	4 years after installation on AED with a battery insertion test and			
	daily self-test but without activating AED*			
Shelf-Life	5 years if stored in its original packaging*			
Туре	Li-Ion Accumulator (rechargeable), code SAV-C1039			
Recharging time	2 hours with the charging station code SAV-C1040 *			
Autonomy	2 years after installation on AED and running only the daily self-diagnosis, but without activating			
	AED*			
Shelf-Life	2 years or 300 charge cycles*			

\*New and fully charged battery at constant temperature of 20°C and non-condensing relative humidity 45%.



# 13 Compliance with electromagnetic emission standards

The following paragraphs will specify the compliance with electromagnetic emission standards:

- Guidelines and manufacturer's declaration Electromagnetic emissions
- Guidelines and manufacturer's declaration Electromagnetic immunity
- Recommended distances between portable and mobile radiofrequency communication equipment and the AED

# 13.1 Guidelines and manufacturer's declaration - Electromagnetic emissions

The *Geo Saver* was designed to be used in electromagnetic environments with features listed below. The customer or the user of the *Geo Saver* must ensure that it is used in such an environment.

Emissions test	Compliance	Electromagnetic environment - Guidelines
RF Emissions CISPR 11	Group 1	The <b>AED</b> uses RF energy only for its internal operation. Therefore its RF emissions are very low and are unlikely to interfere with nearby electronic equipment.
RF Emissions CISPR 11	Class B	The <b>AED</b> can be used in any building, including those for residential use and those directly connected to the public low- voltage power supply network that supplies residential buildings.
Harmonic Emissions IEC/EN 61000-3-2	Not applicable	
Voltage fluctuations / flicker IEC/EN 61000-3-3	Not applicable	

# 13.2 Guidelines and manufacturer's declaration - Electromagnetic immunity

The *Geo Saver* was designed to be used in electromagnetic environments with features listed below. The customer or the user of the *Geo Saver* must ensure that it is used in such an environment.

Immunity test	Test level IEC/EN 60601-1	Compliance level	Electromagnetic environment - Guidelines
Electrostatic shock (ESD)	±6 kV contact	±6 kV contact	Floors must be wood, concrete or ceramic tiles. If the floors are covered with synthetic
IEC/EN 61000-4-2	±8 kV air	±8 kV air	material, the relative humidity must be at least 30%.
Fast transients / bursts	±2 kV by electricity networks	Not applicable	
IEC/EN 61000-4-4	±1 kV by input / output networks	±1 kV by input / output networks	
	< 5% U <sub>T</sub> (> 95% dip in U <sub>T</sub> ) for 0,5 cycles 40% U <sub>T</sub>		
TECTEN (1000 4 11	(60% dip in U <sub>T</sub> ) for 5 cycles		
IEC/EN 61000-4-11	70% U <sub>T</sub> (30% dip in U <sub>T</sub> ) for 25 cycles	Not applicable	
	< 5% U <sub>T</sub> (>95% dip in U <sub>T</sub> ) for 5 seconds		



Imn	nunity test	Test level IEC/EN 60601-1	Compliance level	Electromagnetic environment - Guidelines
Supply frequencies (magnetic fi 50/60 Hz	•	3 A/m	80 A/m	Power frequency magnetic fields must be at levels no higher than those of stations located in typical heavy industrial applications, power plants and control
IEC/EN 61				rooms of high voltage substations.
Note: U <sub>T</sub> is	the main AC current	t before the test level is applied	1	1
RF conducte	ed	3 Vrms	Not applicable	
IEC/EN 61	000-4-6	from 150 kHz to 80 MHz outside of ranges ISM <sup>a</sup> 10 Vrms from 150 kHz to 80 MHz inside the ranges ISM <sup>a</sup>	Not applicable	
RF radiated IEC/EN 610		10 V/m from 80 MHz to 2,5 GHz	10 V/m	The distance between portable and mobile RF communications equipment in use and any part of the AED, including cables, must never be less than the recommended separation distance calculated based on the equation applicable to the transmitter frequency. <b>Recommended separation distance</b> $d = 1.2\sqrt{P}$ from 80 MHz to 800 MHz $d = 2.3\sqrt{P}$ from 800 MHZ to 2,5 GHz Where P is the transmitter's maximum output power range in watts (W) according to the transmitter manufacturer's data and d is the recommended distance in meters (m) <sup>b</sup> . The field strengths of fixed radiofrequency transmitters, as determined by an investigation in electromagnetic sites, should be less than the compliance level in each frequency range. <sup>d</sup> Interference may occur near the devices marked with this symbol.
NOTE 1	From 80 MHz to 8	00 MHz, the higher frequency	range applies.	•
NOTE 1		nay not apply in all situation	0 11	agation is influenced by absorption and reflection from
а		dustrial, scientific and medica Iz; from 26.957 MHz to 27.28		0 MHz are from 6.765 MHz to 6.795 MHz; from 13.553 0 40.70 MHz.
b	The levels of compliance in the ISM bands between 150 kHz and 80 MHz and between 80 MHz and 2.5 GHz are designed t reduce the possibility of interference in the event that portable and mobile communication devices are inadvertently approached t the area where the patient is found. For this reason, an additional factor of 10/3 is added to the calculation of the recommende separation distance for transmitters whose frequencies fall within these ranges.			communication devices are inadvertently approached to of 10/3 is added to the calculation of the recommended
c	cordless) telephone fixed RF transmitte which the AED is	es and mobile radios, amateur ers, consider conducting an e used exceeds the specific RF unctioning. If operating anoma	radio, AM and FM radio lectromagnetic site survey compliance level mentio	ted transmitters, such as base stations for radio (cellular / and TV. To assess the electromagnetic environment with y. If the power of the fields measured in the location in oned above, it will be necessary to monitor the AED to be necessary to take corrective measures, for example by
d	Over the frequency range between 150 kHz and 80 MHz, field strengths must be less than $1 \text{ V} / \text{m}$ .			



# 13.3 Recommended separation distance between portable and mobile RF communication equipment and Geo Saver device

The **Geo Saver** must be used in an electromagnetic environment in which radiated RF interference is controlled. The customer or the operator of the **Geo Saver** can help prevent electromagnetic interference by maintaining the minimum distances recommended below, between the portable and mobile RF communications equipment (transmitters) and the **Geo Saver**, based on the maximum output power of the devices of communication.

Maximum	Separation distance according to the transmitter frequency m			
transmitter power output rate W	From 150kHz to 80 MHz outside the ISM bands	From 150kHz to 80 MHz inside the ISM bands	From 80 MHz to 800 MHz	From 800 MHz to 2,5 GHz
	$d = 1.2\sqrt{P}$	$d = 1.2\sqrt{P}$	$d = 1.2\sqrt{P}$	$d = 2.3\sqrt{P}$
0.01	0,12 m	0,12 m	0,12 m	0,23 m
0.1	0,37 m	0,38 m	0,38 m	0,73 m
1	1,12 m	1,2 m	1,2 m	2,3 m
10	3,7 m	3,8 m	3,8 m	7,3 m
100	12 m	12 m	12 m	23 m

For transmitters rated at a maximum power not listed above, the separation distance "d" in meters (m) can be determined using the equation applicable to the transmitter frequency, where P represents the maximum power produced by the watt transmitter (W) according to the transmitter manufacturer.

NOTE 1:	At 80 MHz and 800 MHz, the separation distance applied is that used for high frequency ranges.			
NOTE 2:	The ISM frequency bands (for industrial, scientific and medical applications) between 150 kHz and 80 MHz are 6,765 MHz up to 6,795 MHz; 13,553 MHz up to 13,567 MHz; 26,957 MHz up to27,283 MHz and 40,66 MHz up to40,70 MHz			
NOTE 3:	An additional factor of 10/3 is used in the calculation of the recommended separation distance for transmitters in the ISM frequency bands between 150 kHz and 80 MHz and in the frequency range from 80 MHz to 2.5 GHz to decrease the possibility that a Mobile / portable equipment may interfere if inadvertently brought into the patient's area.			
NOTE 4:	These guidelines may not be applicable in all situations. Electromagnetic diffusion is influenced by the absorption and reflection of structures, objects and people.			




# 14 Simbology

<b>V</b>	ILCOR Universal Symbols for AED	Ø	IMQ brand
$\bigwedge$	High Voltage Electrical Hazard	CE	CE mark with identification number
$\triangle$	General Notices: Refer to the consultation of accompanying documents before using the appliance	IP56	Degree of protection of the appliance against dust and water (including battery)
Ŕ	Type BF, Defibrillation-proof Equipment	SN	Serial Number
$\otimes$	Do not expose to high temperatures or flames	$\sim\sim$	Manufacturing date
	Do not recharge	LOT	Lot Number (LOT)
	Do not open	$\sum$	Expiration date
	Do not destroy or damage it	REF	Model identifier
	Do not use it in puddles of water		Manufacturer Name
$\mathbf{S}$	Read the User Manual	LATEX	Absence of latex
	Battery recycling	2	Single use, do not reuse
X	Follow local waste regulations	NON	Not Sterile
Ţ	Fragile	0/6	External directions on the box
Ť	Store in a dry place	<u>11</u>	This side up
淡	Do not expose to direct sunlight	1	Temperature Limits
WARNING BU 9 NUT AND A STORY AND A STORY AND	Risk of electric shock do not open	6	Only stack up to 6 cartons in height
	Type CF applied part	$((\cdot,\cdot))$	Non-ionizing electromagnetic radiation



# **15.1 EC Certificate**



Mod. 4606/0





# EC CERTIFICATE

Certificate No 1104/MDD Full Quality Assurance System Approval Certificate

On the basis of our examination carried out according to Annex II, excluding section 4, of the Directive 93/42/EEC and its revised version, we hereby certify that:

#### A.M.I. ITALIA S.R.L.

80143 NAPOLI (NA) - VIA G. PORZIO CENTRO DIREZIONALE IS.G2 (ITA) - Italy

manages in the factory of:

A.M.I. INTERNATIONAL KFT - 2000 SZENTENDRE - KOZUZO u. 5/A (HUN) - Hungary

80010 QUARTO (NA) - VIA CUPA REGINELLA 15A (ITA) - Italy

a quality assurance system ensuring the conformity of the following products:

External cardiac defibrillator

Type ref. as to Document "Defibrillatore Cardiaco Esterno" Rev.0 dated 2018/11/09; valid only if provided with IMQ mark.

with the relevant essential requirements of the aforementioned directive (from design to final inspection and testing) and it is subject to surveillance as specified in section 5 of Annex II. For class III devices, this certificate is valid only with the relevant EC Design-Examination Certificate of Annex II.4.

Reference to IMQ files Nos:

10Al00006; 10AJ00117; COMEDCONMHDM110027747-01; 10EN00018; 10AO00009; DM17-0009799-01; DM17-0018806; DM17-0020656-01; DM18-0023720-01; DM18-0032037-01; DM19-0034531-01.

This Approval Certificate is issued by IMQ S.p.A. as Notified Body for the Directive 93/42/EEC and its revised version. Notified Body notified to European Commission under number: 0051.



# 15.2 IMQ Brand





Emesso II / Issued on	2008-09-25		
Aggiomato il / Updated on	2019-03-04		
Sostituísce / Replaces	2014-03-18		

570/00 D 100



# 16 Geo Saver Series Defibrillator Warranty

#### **1** Warranty Restriction

A.M.I. Italia Srl guarantees the original purchasers that its Geo Saver series defibrillators and related accessories and batteries are free from any material or manufacturing defect according to the terms and conditions of this restrictive warranty. The original purchaser is considered to be the final user of the product purchased. This limited warranty is granted only to the original purchaser of the Geo Saver series defibrillator of A.M.I. Italia srl and is not transferable or assignable to third parties. The Geo Saver One Series defibrillators are as follows: **Geo Saver Semi-Automatic** (code SGS-B0988/SGS-B0989) **Geo Saver Automatic** (code SGA-B0990/SGA-B0991) **Geo Saver D** (code SGD-B0992 / SGD-B0993) **Geo Saver P** (code SGP-B0994 / SGP-B0995)

#### **2** Duration

A.M.I. Italia Srl guarantees the original purchaser of Geo Saver series defibrillators, starting from the date of dispatch\* of the warranty validation form (to A.M.I. Italia Srl) or starting from 30 (thirty) days from the date of shipment from A.M.I. Italia srl, the one that occurs chronologically first; defibrillators have a typical life expectancy of about 10 years. The guarantee offered by A.M.I. Italia Srl covers a period equal to:

- AED Geo Saver Series have a six (6) year warranty

- **Non-rechargeable batteries Li-SOCl<sub>2</sub>** (SAV-C1032) if installed in the AED and in Standby mode they are guaranteed for 4 (four) years assuming a battery activation test, daily self-tests, without the AED being switched on at the following environmental conditions temperature (20  $^{\circ}$  C) and humidity S / C (45 %)

- Rechargeable batteries Li-Ion (SAV-C1033) are guaranteed for two (2) years from the date of production only if the temperature conditions (temperature 20  $^{\circ}$  C) and humidity (45%) are met and if they are recharged at least one (1) time every four (4) months

- The disposable pads guaranteed until their expiration date.

- All **other accessories** are guaranteed for six (6) months starting 30 days after the original shipping date from our warehouse.

\*The date shown on the registered letter with return receipt will still be valid

#### **3 Procedure**

Please complete (in its entirety) the limited warranty validation form and send it by post (Registered letter A / R) to A.M.I. Italia Srl. The date shown on the A / R recommendation will prevail. You will find the Warranty validation form attached to the user manual or inside the original packaging of the Geo Saver series defibrillator. In the event that a defect covered by this warranty is found, the original purchaser must contact the reference retailer or an authorized A.M.I. Italia Srl.

A.M.I.. Italia Srl reserves the exclusive right to repair or replace the product.

#### 4 Exclusions

This warranty does not cover non-conformities subsequent to purchase, such as those caused by accidents, modifications, negligence, incorrect use or abuse, non-compliance with procedures or hazards, or warnings or cautions described in the user manual, failure to perform a reasonable and adequate maintenance, incorrect installation, replacement of parts and accessories that do not comply with the specifications provided by AMI Italia Srl, any modifications made to the device and in general all subsequent non-conformities deriving from failure to comply with the provisions contained in the user manual. This warranty does not cover, as it does not constitute cases of original non-conformity, the normal wear and tear of components subject to decay during use such as buttons, LEDs and battery contacts. This warranty will also be automatically invalidated in one of the following cases:

- if the Geo Saver AED series serial number is modified, deleted, rendered illegible or otherwise tampered with;

- if the warranty seal (opening of the device) on the Geo Saver DAE is removed;

- in case the commercial name of the product or manufacturer is covered, modified or canceled

Finally, this warranty does not apply to used Geo Saver series AEDs sold, in which case the warranty must be offered by the reseller of the used product with the exclusion of any liability, even indirect, borne by A.M.I. Italia Srl

#### 5 Damage

Except as explicitly provided in this warranty, A.M.I. Italia Srl, WILL NOT BE LIABLE FOR ANY INCIDENTAL OR INDIRECT DAMAGES ARISING FROM THE USE OF THE GEO SAVER SERIES DEFIBRILLATOR OR CLAIMS IN VIRTU OF THIS AGREEMENT, WETHER THE CLAIM REFERS TO THIS AGREEMENT, TO ILLEGAL OR OTHERWISE. The warranty statements mentioned are exclusive and replace any other remedy. Some states do not allow the exclusion or limitation of incidental or indirect damages, so the above limitation or exclusion may not be relevant.

#### 6 Waiver

ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND ALL IMPLIED WARRANTIES ARISING OUT OF NEGOTIATIONS, USE OR BUSINESS CONSUMPTIONS, BY STATUTE OR OTHERWISE ARE STRICTLY LIMITED TO THE TERMS OF THIS WRITTEN WARRANTY. This warranty will be your sole and exclusive buyer's remedy for this purchase. In the event of an alleged violation of any guarantee or legal action brought by the original purchaser for alleged negligence or other unlawful conduct by A.M.I. Italia Srl, the sole and exclusive remedy of the original purchaser will be constituted by the repair or replacement of the resulting defective materials, based on what was previously established. No retailer or agent or employee of A.M.I. Italia Srl is authorized to make changes, extensions or additions to this warranty.

#### 7 Territorial limit

This warranty is valid for products purchased in one of the countries of the European Union or in the countries in which the EU laws and regulations apply.

#### 8 Warning

Install, use and maintain Geo Saver series defibrillators by A.M.I. Italia Srl in absolute compliance with the instructions contained in the user manual

#### 9 Other rights

This limited warranty guarantees the original purchaser specific legal rights; any other rights may vary depending on the state of belonging.


#### 10 Applicable law

Any dispute relating to this agreement or arising from the use of Geo Saver series defibrillators by A.M.I. Italia Srl will be governed by Italian law, at the Court of Naples, Italy



# 17 Product registration

In order to guarantee a correct and rapid traceability of the product sold, we ask you to complete the form below and send it by fax or registered letter to A.M.I. Italia S.r.l.







# AEDs



